

Curved Shower Rods

Before installing please take time to read the installation instructions.

Unpack and inspect the product for any shipping damages.

If you find any damages, do not install, Contact customer service at 888-315-8816.

For all other inquires contact Customer Service.

Preferred Bath Accessories Inc. accepts no liability for any damage to the installation area or for personal injury during installation. It is recommend that you consult a professional if you are unfamiliar with installing bathroom fixtures.



General Information

- To avoid the risk of property damage, do not secure the wall brackets to acrylic shower walls. Instead, secure the wall brackets above the acrylic tub into the finished walls.
- Wall anchors must be used, unless you encounter a stud.
- Non- adjustable rods may be cut to fit by cutting equal amounts on both sides. Example: If total opening is 59" it will require 1/2" angle cut off each end.

Adjustable Curved Shower Rods

Tools and Materials Included

- Allen Wrench (qty 1)
- Wall Anchors (qty 4)
- Mounting Screws (qty 4)
- Set Screws (qty 2)
- Mounting brackets (qty 2)
- Rod Receiver (qty 2)
- Curved Rod (qty 1)

Tools Needed for Installation (not included)

- Phillips Head Screwdriver
- Drill
- Drill Bits
- Level
- Tape Measurer

Installations Instructions

1. Remove all items from box.
2. Place wall bracket onto wall where desired. Make sure it's level, use a pencil to lightly mark desired screw placement. Repeat for other side.
3. Use provided stainless steel screws to mount wall brackets to the wall.
4. Installing the curved shower rod.
 - a. **FIRST**
 - i. Grab the rod receiver that is NOT already installed on the curved shower rod. Join this to the mounting brackets you've already installed onto the wall. Line up the T-plug on the bar receiver with the T-plug hole on the wall bracket, insert and rotate counter clockwise to lock into place.
 - b. **SECOND**
 - i. Installing the smaller curved shower rod side.
 1. Line up the T-plug on the bar receiver with the T-plug hole on the mounting bracket, rotate counter clockwise to lock into place (**Do not let go of the shower rod until you do the next step. This will prevent any damage to the T-plug**)
 2. (**If using a shower curtain that does not require hooks please install now**). Pull the large side of curved shower rod extending the rod towards the empty bar receiver. Once these two meet rotate both the rod and bar receiver until the rod slides into the bar receiver. Once the curved shower rod is inserted use the provided set screw and lock it down with the provided allen key. Enjoy your new curved shower rod.

Fixed Curved Shower Rods

Tools and Materials Included

- Allen Wrench (qty 1)
- Wall Anchors (qty 4)
- Mounting Screws (qty 4)
- Set Screws (qty 2)
- Mounting brackets (qty 2)
- Rod Receiver (qty 2)
- Curved Rod (qty 1)

Tools Needed for Installation (not included)

- Phillips Head Screwdriver
- Drill
- Level
- Tape Measurer

Installations Instructions

1. Remove all items from box.
2. Place wall bracket onto wall where desired. Make sure it's level, use a pencil to lightly mark desired screw placement. Repeat for other side.
3. Use provided stainless steel screws to mount wall brackets to the wall.
4. Installing the curved shower rod.
 - a. **FIRST**
 - i. Grab both rod receivers. Join these to the mounting brackets you've already installed onto the wall. Line up the T-plug on the bar receiver with the T-plug hole on the wall bracket, insert and rotate counter clockwise to lock into place.
 - b. **SECOND**
 - i. Installing the curved shower rod.
 1. (**If using a shower curtain that does not require hooks please install now**). Insert the curved shower rod into one side bar receiver, rotate the curved shower rod while still inside the bar receiver towards the second empty bar receiver. Once these two meet rotate both the curved shower rod and bar receiver until they meet. Pull the curved shower rod towards the second bar receiver and insert. Once rod is inserted use the provided set screws and lock the curved shower rod down with the provided allen key on both sides. Enjoy your new curved shower rod.