


Kitchen Islands Carts

Assembly Instructions - Please keep for future reference



Dimensions

Width-46 inch

Depth-18 inch

Height-36.25 inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type


Components - Fittings

Please check you have all the panels listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)  Dowel x43	(B)  Cam Bolt x44	(C)  Cam lock x24	(D)  Male Camlock x20
(E)  4*50mm Screw x15	(F)  4*35mm Screw x25	(G)  Handle x6	(H)  4*18mm Bolt x6
(I)  Door Hinge x2	(J)  3.5*14mm Screw x12	(K)  Drawer slide 14" x10	(L)  3.0*12mm Screw x60
(M)  Shelf Support Pin x8	(N)  6*32mm Bolt x8	(O)  6*90mm Bolt x6	(P)  Flat Washer x6
(Q)  Lock Washer x6	(R)  Allen Key x1	(S)  Locking Caster x2	(T)  Caster x3
(U)  6*15mm Bolt x20			



Tools required



Phillips screwdriver
(medium & large)



Ruler - Use this ruler to help correctly identify the screws



The screws length is measured from the head to the point (35mm screw shown).


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4



Adjusting Hinges

Hinge adjustment:


a: To move the top panel up or down, loosen screws shown and move top panel to suit

b. To move the top panel in or out, loosen screws shown and move top panel to suit.


Retighten screws

C: To move the top panel left or right, adjust screws shown.


a:




b:



c:




Assembly Instructions




Assembly Instructions

Step 1




(K)




Drawer slide 14" x10

Step 2




(B)



Cam Bolt x5

(K1)



Drawer slide 14" x3


(L)





3.5*12mm Screw x9

Assembly Instructions

Step 3




Step 4



Assembly Instructions

Step 5




(A)



Dowel x4

Step 6






(F)






4*35mm Screw x4

Assembly Instructions

Step 7





Step 8





Assembly Instructions

Step 9





Step 10




Assembly Instructions

Step 11





Step 12







Assembly Instructions

Step 13





Step 14





Assembly Instructions

Step 15




Step 16





Assembly Instructions

Step 17




Step 18



Assembly Instructions


Step 19

 6*90mm Bolt x6	 Flat Washer x6	 Lock Washer x6	 Allen Key x1
---	---	---	---




or

 Allen Key x1	 Caster x3
 Locking Caster x2	 6*12mm Bolt x20




Assembly Instructions

Step 20



Step 21





Assembly Instructions

Step 22

(C)



Cam lock x2




Step 23

(A)



Dowel x4



Assembly Instructions

Step 24

C





Cam lock x4

F




4*35mm Screw x1



Assembly Instructions

Step 25





(M)



Shelf Support Pin x8


Step 26



Assembly Instructions


Step 27

(B)



Cam Bolt x20

(K2)





Drawer slide 14" x10

(L)



3.0*12mm Screw x30




Step 28

(F)






4*35mm Screw x20



Assembly Instructions




Step 29

(G)  Handle x3	(H)  4*18mm Bolt x3	(D)  Male Camlock x12
---	--	--




Step 30

(G)  Handle x2	(H)  4*18mm Bolt x2	(D)  Male Camlock x8
---	--	---





Assembly Instructions

Step 31



Step 32



Assembly Instructions

Step 33

J



3.5*14mm Screw x8

