## **CARE AND MAINTENCE**

Wipe clean with a soft, dry cloth. The seat board can be cleaned with a mild cleaner. Test the cleaning method on a hidden area before using them over the entire area.

## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item.
- \* This item should be assembled on a soft surface to prevent scratching the finished product during assembly.
- \* This item may require periodic tightening.
- \* Do not tighten bolts until completely assembled.


## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Drawer	0	1 X
В	LEG		4 X
HW1	HEX SOCKET BOLT 5/16"-18 x 1-3/4"		8 X
HW2	ALLEN KEY 4mm		1 X
HW3	ANTI-TIP HARDWARE	S,	1 X



Model# NST6408

Product Dimensions: 18"W x 18"D x 24"H






Weight Capacity: 25 lbs on top of the product

Warning: Do not stand on the product Warning: Do not over torque bolts


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 20 minutes.


Tools Required for Assembly (included): Allen Key .



Step 1: Take 4\*Legs (B) from a box where on the cabinet shelf.



Step 2: Attach the 4\*legs (B) to the bottom side of Drawer (A), And use the Allen Key (HW2) to lock with 8\*Hex Socket Bolts (HW1), as picture.



Step 3: Straighten up the assembled product. Following the installation instructions of anti-tipping (HW3) to fix the product in the wall by strap. Assembly is completed.