


ASSEMBLY INSTRUCTIONS



WARNING!

Serious or fatal injuries can occur from furniture tip over. Use tip over restraint (provided) to secure this product to the wall.

Description : BROOKLYN 3 DRAWER NIGHTSTAND
Item No. : BD-8013

BEFORE ASSEMBLY


Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.












WARNING:

Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.






PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Top	1		B	Side panel (L-R)	2	
C	Bottom panel	1		D	Back panel	1	
E	Upper Drawer front	1		F	Upper Drawer side (L-R)	2	
G	Upper Drawer back	1		H	Lower Drawer front	2	
I	Lower Drawer side (L-R)	4		J	Lower Drawer back	2	
K	Drawer bottom	3					

HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Bolt (M6 x 30mm)	8		2	Spring Washer (Φ6.5 x 11mm)	8	
3	Flat Washer (Φ6.5 x 13mm)	8		4	Screw (M4 x 35mm)	24	
5	Wooden Knob (Φ30 x 30mm)	3		6	Pan head screw (M4 x 25mm)	3	
7	Allen key (M4 x 30mm x 110mm)	1		8	Short Pan head screw (M4 x 15mm)	2	
9	Long Pan head screw (M4 x 50mm)	2		10	Steel Tip Bracket	4	
11	Flat Nylon Tie	2					

NOTE: WARNING LABEL (INCLUDED)

▲ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***


STEP 1

Attach top (A) and bottom panel (C) to side panel (B) with bolts (1), and washers (2) and (3) as shown below. Tighten with Allen key (7).
Slide back panel (D) into the grooves as shown below.



STEP 2


Attach bottom panel (C) and top (A) to the other side panel (B) with bolts (1), and washers (2) and (3), as shown below. Tighten with Allen key (7).



STEP 3


Attach drawer sides (F) to drawer front (E) with screws (4) as shown below. Tighten with a screwdriver. Insert drawer bottom (K) into the grooves at bottom of drawer sides (F) and drawer front (E) as shown below.

Attach drawer back (G) to drawer sides (F) with screws (4) as shown below. Tighten with a screwdriver.




STEP 4

Attach knob (5) to front of drawer with pan head screw (6) as shown below. Tighten with a screwdriver. Carefully put the drawer into the unit.




STEP 5

Attach drawer sides (I) to drawer front (H) with screws (4) as shown below. Tighten with a screwdriver. Insert drawer bottom (K) into the grooves at bottom of drawer sides (I) and drawer front (H) as shown below.




STEP 6

Attach drawer back (J) to drawer sides (I) with screws (4) as shown below. Tighten with a screwdriver.



STEP 7

Attach knobs (5) to front of drawers with pan head screws (6) as shown below. Tighten with a screwdriver. Carefully put the drawers into the unit.



STEP 8

Attach brackets (10) to the back of the unit with screws (8) through the smaller holes in the brackets as shown below.

Important!

Properly attach the other brackets (10) to the wall in an area of ***drywall or plaster with a wood stud***: Mark the attachment point(s) with a pencil at the appropriate height **positioned over the wood stud(s) in the wall**.

Place the unit into position so both mounting brackets are vertically in line.

Adjust the levelers to the appropriate height to level the unit.

Properly attach the other brackets (10) to the wall stud with screws (9) through the smaller holes as shown below.

Lace the end of flat nylon ties (11) through the larger holes in each mounting bracket. Bring both ends together and slide the flat ends through the locking ends and draw it through until all slack is removed.

Confirm that the strap is securely laced and locked.

