


INSTALLATION INSTRUCTIONS







NO	PART NAME	QTY
1	Faucet Spout	1
2	Hot Water Handle Parts	1
3	Cold Water Handle Parts	1
4	Pop- up Drain Stopper	1
(5)	Water Supply Hose	2
6	Quick Connector Hose	1
7	Instructions	1

Three faucet styles







1. Unscrew the lock nut and bottom washer from drain stopper



2. Put the pop up drain stopper into sink hole




3. Re-screw the bottom washer and lock nut onto drain stopper




4. Check for leakage and finish


INSTALLATION INSTRUCTIONS




 Slotting three holes in your bathroom sink (the holes' distances as shown in the photo 1)



2. Place the faucet body and handles into sink holes, screw the plastic washer, metal washer and locking nut to the thread pipe of the faucet as photo 2




3. Adjust the position of the faucet and the handles then hand tighten the locking nut and then use a screwdriver to tighten the screws on the locking nuts to secure the faucet





4. Push the blue button on the quick connect hose and insert the hose to the faucet and the handles' pipe as photo 4

Check and make sure the quick connect hose is well connected



5. Screw the water supply lines to the faucet body, the handles and the stop valves





Then let the water run for 30 seconds