


Resin Garden Shed

OWNER'S MANUAL Instructions for Assembly



SLD-C35-V4

2025-05-27

Requires three people and take 3-4 hours for installation.
Quick & Easy assembly. Ridge Reinforced Walls.
Available in Various Sizes.

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.

Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results. Please be aware: this unit takes three people about 3-4 hours to complete.









Parts

Check to be sure that you have all the necessary parts for the building.

Separate contents of the carton by the part number while reviewing parts list.


Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS MAY REQUIRED



Use heavy duty gloves when handling steel sheets and flashing

PLAN AHEAD



Watch the weather:

Please be sure the day you select for installation is dry and calm.

DO NOT attempt to assemble your shed in windy weather because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels

PLAN AHEAD

Site Selection

Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.

Small trees, bushes or fences nearby can be helpful, acting as a wind break.

Site Preparation

The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete, in order to stop the moisture getting into the shed. The shed is not designed to be built onto lawn directly. Also the ground will get muddy during rainy days.

If a concrete pad is made, it is important that this slopes towards the edges to prevent water ingress.

Time must be allowed for any concrete or cement to dry before building the shed on top.

Bases can also be constructed from bricks, blocks, or mounted on a concrete pad.

The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.

IMPORTANT NOTES:

Find someone to help you: it is much easier with someone to hold parts, pass tools ect. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.

































Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.
















Have the right tools to hand.







Safety clothing as recommended in the 'Tools' section.


Ideally lay out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.

Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.

| | | | | | | | | | | | |
|---------|--|-----|------------|---|-----|------------|---|-----|------------|---|-----|
| C35-C01 |  | x 1 | C35-C09 |  | x 1 | C35-C18 |  | x 2 | C35-V4-A02 |  | x 1 |
| C35-C02 |  | x 1 | C35-C10 |  | x 3 | C35-C19 |  | x 2 | C35-A03 |  | x 2 |
| C35-C03 |  | x 1 | C35-V4-C01 |  | x 2 | C35-C18-1 |  | x 2 | C35-A04 |  | x 1 |
| C35-C04 |  | x 1 | C35-V4-C02 |  | x 1 | C35-C19-1 |  | x 2 | C35-A05 |  | x 1 |
| C35-C05 |  | x 2 | C35-C13 |  | x 2 | F35-C27 |  | x 4 | C35-A06 |  | x 4 |
| C35-C06 |  | x 1 | C35-C14 |  | x 2 | F35-C29 |  | x 8 | C35-V4-A03 |  | x 1 |
| C35-C07 |  | x 1 | C35-C15 |  | x 2 | F35-C30 |  | x 4 | C35-V4-A04 |  | x 1 |
| C35-C08 |  | x 1 | C35-C16 |  | x 2 | C35-V4-A01 |  | x 1 | C35-A09 |  | x 4 |


| | | | | | | | |
|------------|---|-----|--|-----|---|-------|--|
| C35-A12 |  | x 2 | | E01 |  | x 36 | |
| C35-V4-A05 |  | x 2 | | E02 |  | x 212 | |
| A86-D01 |  | x 2 | | E03 |  | x 24 | |
| C35-D02 |  | x 2 | | E04 |  | x 4 | |
| A64-A15 |  | x 4 | | E05 |  | x 4 | |
| F35-C34 |  | x 1 | | E06 |  | x 4 | |
| D03 |  | x 1 | | E11 |  | x 4 | |
| | | | | E12 |  | x 28 | |








C35-C02 x1



C35-C01 x1




(ST4.2x12)
E02x3

Basement Pre-assembly

A

I




Place the panel smooth side up, knock the panel tightly by using hammer to make sure the panel is tightly fitted. This will prevent leaks, and then secure it with screws.

It is recommended to have three people install this at the same time, this will help with a better installation.

Note: All panels have a rough side and a smooth side. When installing, make sure that the smooth side is toward the inside of the storage shed.

There are card slots on all panels. Align the panel and push it directly with force when installing panels; if it can't be pushed, you can stand the panel up and use the sliding type installation

II






C35-C09 x1



C35-C08 x1




(ST4.2x12)
E02x3


Side wall Pre-assembly

B

I




II






C35-C06 x1



C35-C07 x1




(ST4.2x12)
E02x3


Side wall Pre-assembly


C

I




II





C35-C10 x3




(ST4.2x12)
E02x6


Back wall Pre-assembly

D

I



II







C35-V4-C01 x2



C35-V4-C02 x1



C35-V4-A05 x2




(ST4.2x12)
E02x8


Roof Pre-assembly






E

I




II









Door Pre-assembly

F-1





Note: Please kindly confirm the diagonal distance "X" of the door should be same before assembling the screws.






Back wall Pre-assembly


F-2




$$X = X$$

Note: Please kindly confirm the diagonadistance "X" of the door should be same before assembling the screws.






C35-D02 x2




C35-A12 x2




E06 x4



(M8x25)
E05x4





(ST4.2x13)
E01x4



F-1

F-2







C35-V4-A04 x1






C35-C13 x2



Ax1




Please use rubber-knife to helping assembly.







C35-C14 x2








F35-C27 x4



(ST4.2x12)
E02x20




Please use rubber-knife to helping assembly.









C35-C16 x1



Bx1




Dx1





Please use rubber-knife to helping assembly.




C35-C16 x1



Cx1




Please use rubber-knife to helping assembly.









C35-C15 x2




(ST4.2x12)
E02x13








C35-V4-A01 x1




C35-V4-A02 x1




(ST4.2x12)
E02x2








C35-V4-A03 x1







(ST4.2x12)
E02x8








C35-A09 x2









(ST4.2x12)
E02x37









C35-A09 x2






(ST4.2x12)
E02x37





(ST4.2x12)
E02x14








C35-C18 x2




C35-C19 x2





Ex1








C35-C18-1 x2




C35-C19-1 x2




(ST4.2x12)
E02x14








F35-C30 x4







(ST4.2x12)
E02x16








(ST4.2x12)
E02x18








(M4x10)
E12x12





(ST4.8x19)
E03x24





E04x4

