

If you have any questions, please feel free to contact us. Email: lowesteam@aminalife.com







NO	PART NAME	QTY	NO	PART NAME	QTY
1	Faucet Spout	1	(5)	Water Supply Hose	2
2	Hot Water Handle Parts	1	6	Quick Connector Hose	1
3	Cold Water Handle Parts	1	7	Instructions	1
4	Pop- up Drain Stopper	1		1	

Six faucets styles






Unscrew the lock nut and bottom washer from drain stopper



2. Put the pop up drain stopper into sink hole




3. Re-screw the bottom washer and lock nut onto drain stopper




4. Check for leakage and finish

INSTALLATION INSTRUCTIONS




 Slotting three holes in your bathroom sink (the holes' distances as shown in the photo 1)



2. Place the faucet body and handles into sink holes, screw the plastic washer, metal washer and locking nut to the thread pipe of the faucet as photo 2




3. Adjust the position of the faucet and the handles then hand tighten the locking nut and then use a screwdriver to tighten the screws on the locking nuts to secure the faucet




4. Push the blue button on the quick connect hose and insert the hose to the faucet and the handles' pipe as photo 4

Check and make sure the quick connect hose is well connected



5. Screw the water supply lines to the faucet body,the handles and the stop valves



6. Turn on water supply to check for leakage.

Then let the water run for 30 seconds