Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www. quoizel. com

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-TF1139T For Style TF1139T

Tools Required: None

Bulb Recommended: (1) Medium Base 60W Maximum

Estimated Assembly Time: 15-20 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity
Α	Harp	1 pc.
В	Base	1 pc.
С	Finial	1 pc.
D	Shade	1 pc.
Е	Flat Washer	1 pc.




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

November 2011





(1)60W Medium Base Bulb (Not Supplied)

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/2"

NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.	
1	11139TTF	BASE TF1139T	1	
2	M2259FI	FINIAL 0.72"D X 1.40"H	1	
3	G2858SH	SHADE TIFFANY 10.5"SQ X 9.5"H	1	


2of3

Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www. quoizel. com

Assembly Instruction Sheet #IS-TF1139T For Style TF1139T


STEP 1 - Install Harp

A. Locate the Harp (A) by pressing the ends of the Harp (A) into the Harp Clips.



STEP 2 - Assemble Shade


A. Place the Flat Washer (E) and Shade (D) over the top end of the Harp (A). Secure by thread the Finial (C) onto the Harp (A). Hand tighten until snug.



STEP 3 - Install Bulb

- A. This fixture uses standard bulbs with medium screw bases. Maximum 60 watts.
- B. Insert bulb and screw snugly into place.

Your fixture table lamp is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

Overable 2011 Quoizellnc.