

SECURITY DOOR

Spanish en el reverso

PACKAGE CONTENTS

A



PART	DESCRIPTION	QUANTITY
A	Security Door	1


Styles may vary

PACKAGE CONTENTS

PART	DESCRIPTION	QUANTITY
AA	4 in. one-way screws	8
BB	Top bar	1
CC	Locking side bar	1
DD	One-way tool	1

NOTE: All parts not shown at actual size.


AA



CC



BB





DD



PREPARATION

Tools Recommended for Assembly

Drill 3/16 in. bit, level or string plumb, and pencil.

**IMPORTANT:** Read all instructions carefully before starting installation.**NOTE:** One-way screws are non-removeable once installed.

Questions, problems, missing parts?

Before returning to your retailer, call our customer service department at 1-800-222-3667.

ASSEMBLY INSTRUCTIONS

1. Identify which way the security door is to open (Fig. 1).



FIGURE 1

2. Install the lockset (sold separately) with 2-3/8" backset. Then, fully extend the lock bolts into the "locked" position (Fig. 2).




FIGURE 2

3. Place security door in front of opening at desired height, making sure that the security door is vertical (plumb). Determine where to drill by marking through the pre-drilled holes on the **hinge-side jamb** with pencil (Fig. 3).




FIGURE 3

4. Drill holes. Using the one-way security lag screws, fasten door to house. **Tighten lag screws only halfway**, at this time, in case repositioning the door is required later (Fig. 4).




FIGURE 4

5. Align the **lock bolt holes** in the **lock-side jamb** with the extended lock bolts, making sure the jamb is vertically true (plumb) (Fig. 5).




FIGURE 5

6. Mount lock-side jamb to door frame jamb. Drill holes. Fasten lock-side jamb to the house, using the **one-way security lag screws**. **Tighten lag screws only halfway** at this time. When you are satisfied with the position and operation of the security door, tighten lag screws securely to the house (Fig. 6).




FIGURE 6

7. Insert plugs in ends of header. Mount header jamb at top of door using remaining 2 one-way screws. Leave approximately 1/8 in. space between header jamb and top of door frame (Fig. 7).




FIGURE 7

MAINTENANCE

1. Security doors are finished with a heavy-duty powder coat finish. In order to maintain your finish we require cleaning and waxing the security door 2 times per year, preferable late fall and early spring. Doors directly subjected to the sun, salt-air or moisture may require more maintenance.
2. Any scratches or abrasions to the door finish must be immediately touched up with enamel or rust protective paint.
3. To keep your door looking like new, any signs of rust should be sanded with mild sandpaper and touched up immediately with enamel or rust protective paint.
4. Hinges and lockset (sold separately) should be oiled and lubricated regularly to reduce friction wear.
5. Make sure any sprinklers near your new door are directed away.
6. Do not allow vegetation on your security door. This will lead to extra maintenance.
7. Make sure to keep your weed eater and lawn mower away from your security door. It may create unwanted chips to your door finish.

WARRANTY

5-YEAR LIMITED WARRANTY
Monterey, Pasadena

3-YEAR LIMITED WARRANTY
Alexandria, Cherokee, Sunburst, Sunset, Gibraltar Max

1-YEAR LIMITED WARRANTY
Covington, Gibraltar, Magnum, Sonoma, Ventura

This Warranty applies if you are a residential purchaser and covers—under normal and proper use and normal conditions, and as long as the product was properly installed in accordance with the Installation Instructions provided with the product—any defects or malfunctions relating to the structural integrity of your Comfort Bilt® product's metal structure and framing, including all welding.

What are Comfort Bilt®'s obligations under the Warranty? If any part covered by the Warranty, when properly used, is found upon inspection to be defective, Comfort Bilt® will repair or replace the defective product or part(s), without charge. Replacements will be made with the same or a comparable quality model, and may not be the same color or style as the original due to changes and discontinuances in styles. Comfort Bilt® shall not be responsible for securing the affected property while products are being repaired or replaced. **How long does the Warranty coverage last?** The Warranty terminates if you sell or otherwise transfer the product or the property on which it was installed. **How do I make a claim under the Warranty?** To make a claim under the Warranty, send (a) a brief written description of the problem and (b) proof of purchase of your Comfort Bilt® product—consisting of the original receipt, showing the date and place of purchase, and the purchase price—to Comfort Bilt®, 2333 Eastbrook Drive, Brookings, SD 57006, Attn: Warranty Claims. Comfort Bilt® reserves the right to inspect any product before making any adjustment covered by this Warranty. **What does this Warranty NOT cover?** This Warranty does NOT cover any defect or problem caused by abuse, misuse (including, but not limited to, improper installation), failure to provide proper maintenance of the warranted product, adjustments due to the settling of the structure in which the product is installed, normal wear and tear or acts of God. In addition, the Warranty does not cover screen material which is pushed out of its groove and damage to your home, loss of property or personal injury or death caused by vandals, break-ins, or attempted break-ins. This Warranty is null and void if you adjust, alter and/or modify the product in any way. This Warranty does NOT cover damages in excess of the purchase price of the product, and UNDER NO CIRCUMSTANCES SHALL COMFORT BILT® BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES WITH RESPECT TO ECONOMIC LOSS OR PERSONAL INJURY OR PROPERTY DAMAGE, WHETHER AS A RESULT OF A BREACH OF AN EXPRESS OR IMPLIED WARRANTY, NEGLIGENCE OR OTHERWISE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the limitation set forth above may not apply to you, in whole or in part. ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARISING UNDER STATE LAW ARE LIMITED IN DURATION TO THE PERIODS OF COVERAGE PROVIDED IN THIS WARRANTY. Some states do not permit limitations on the duration of an implied warranty, so the limitation set forth above may not apply to you. The terms of this Warranty cannot be changed except in writing by an officer of Comfort Bilt®. **How does state law relate to this Warranty?** This Warranty gives specific legal rights only to the original retail purchaser; you may have other legal rights that vary from state to state.

PUERTAS DE SEGURIDAD

CONTENIDO DEL PAQUETE




A

PIEZA	DESCRIPCIÓN	CANTIDAD
A	Puertas de seguridad	1

ADITAMENTOS

PIEZA	DESCRIPCIÓN	CANTIDAD
AA	Tornillos de una vía de 4 pulg	8
BB	Barra superior	1
CC	Barra de bloqueo lateral	1
DD	Herramienta unidireccional	1


NOTA: no se muestran todas las partes en el tamaño real.



PREPARACIÓN

Herramientas necesarias para el ensamblaje

Broca para taladro de 3/16 pulg, nivel o plomada y lápiz.



IMPORTANTE: lea con atención todas las instrucciones antes de comenzar la instalación.
NOTA: Los tornillos unidireccionales no se pueden desmontar una vez instalados.

?Preguntas, problemas, piezas faltantes?



Antes de volver a la tienda, llame a nuestro departamento de servicio al cliente al 1-800-222-3667.

INSTRUCCIONES DE ENSAMBLAJE

1. Identifique la dirección en la que se va a abrir la puerta de seguridad (Fig. 1).



FIGURE 1

2. Instale el juego de cerrjos (se vende por separado) con un seguro posterior de 2-3/8 pulg. Luego, extienda por completo los pernos de fijación en la posición de bloqueo (Fig. 2).




FIGURE 2

6. Monte la jamba del lado del seguro a la jamba del marco de la puerta. Perfore los orificios. Sujete la jamba del lado del seguro a la casa, usando los tornillos tirafondo a la mitad. Cuando esté satisfecho con la posición y el funcionamiento de la puerta de seguridad, ajuste firmemente los tornillos tirafondo a la casa (Fig. 6).




FIGURE 6

3. Ubique la puerta de seguridad en frente de la apertura a la altura deseada, asegurándose de que la puerta de seguridad esté vertical (plomada). Determine el lugar a perforar marcando con un lápiz a través de los orificios pretaladrados en la jamba del lado del seguro (Fig. 3).




FIGURE 3

4. Perfore los orificios. Usando los tornillos tirafondo de seguridad de una vía, sujete la puerta a la casa. Ajuste los tornillos tirafondo sólo hasta la mitad, esta vez, en caso de que luego se requiera volver a colocar la puerta (Fig. 4).




FIGURE 4

7. Las puertas de seguridad están terminadas con un acabado de capa granulada muy resistente. Para mantener su acabado es necesario limpiar y encerar la puerta de seguridad dos veces al año, preferentemente a fines del otoño y principio de la primavera. Las puertas que están expuestas directamente al sol, a un medio salino o a la humedad pueden necesitar más mantenimiento.

2. Cualquier rayón o abrasión en el acabado de la puerta se debe retocar con esmalte o pintura antioxidante.

3. Para que su puerta siempre luzca como nueva, todos los signos de óxido se deben lijar con un papel de lija suave y se deben retocar con esmalte o pintura antioxidante.

4. Las bisagras y el juego de cerrojo (se vende por separado) se deben aceitar y lubricar regularmente para reducir el desgaste por la fricción.

5. Asegúrese de que los rociadores que están cerca de su puerta no estén dirigidos hacia ella.

6. No permita que crezca vegetación en su puerta de seguridad. Esto provocará que necesite más mantenimiento.

7. Asegúrese de mantener su podadora lejos de su puerta de seguridad. Puede crear astillas no deseadas en el acabado de su puerta.

GARANTÍA

GARANTÍA LIMITADA DE 5 AÑOS
Monterey, Pasadena

GARANTÍA LIMITADA DE 3 AÑOS
Alexandria, Cherokee, Sunburst, Sunset, Gibraltar Max

GARANTÍA LIMITADA DE 1 AÑOS
Covington, Gibraltar, Magnum, Sonoma, Ventura

Esta Garantía se aplica si usted es un comprador residencial y cubre, bajo el uso normal y adecuado y bajo condiciones normales, siempre y cuando el product haya sido instalado de acuerdo con las instrucciones de instalación provistas con el producto. Todos los defectos o fallas relacionadas con una inspección se descubre que cualquier pieza cubierta por la Garantía, al usarse correctamente, tiene un

total la solidadura. ¿Cuáles son las obligaciones de Comfort Bilt® bajo la Garantía? Si luego de una inspección se descubre que cualquier pieza cubierta por la Garantía, al usarse correctamente, tiene un

defecto, Comfort Bilt® reparará o reemplazará el producto o pieza(s) defectuosos, sin cargo. Los reemplazos se realizarán con el mismo modelo o uno de calidad comparable, y es posible que no sea del mismo color o estilo que el original debido a cambios y discontinuaciones en los estilos. Comfort Bilt® no se hará responsable de la seguridad de la propiedad afectada mientras los productos se reparan

o reemplazan. ¿Cuánto dura la Garantía? La Garantía termina si usted vende o transfiere de otra manera el producto o la propiedad en la que está instalado. ¿Cómo debo exponer un reclamo en virtud de esta Garantía? Para exponer un reclamo bajo la Garantía, envíe a Comfort Bilt®, 2333 Eastbrook Drive, Bookings, SD, 57006. At: Reclamaciones de la Garantía, (a) una breve descripción por escrito del

problema y (b) un comprobante de compra de su producto Comfort Bilt®, que es el recibo original, que muestra la fecha y el lugar de compra y el precio de la compra. Comfort Bilt® se reserva el derecho de inspeccionar cualquier producto antes de realizar cualquier ajuste cubierto por esta Garantía. Lo que NO cubre esta Garantía? Esta Garantía NO cubre ningún defecto o problema causado por abuso,

mal uso (incluyendo, entre otros, la instalación incorrecta), no brindar el mantenimiento adecuado del producto con garantía, ajustes debidos al asentamiento de la estructura en la que instaló el producto, desgaste debido al uso normal o desastres naturales. Además, la Garantía no cubre el material de la malla que se saca de su ranura y el daño a su hogar, pérdida de propiedad o lesión personal o muerte

causada por vándalos, ladrones o intentos de robo al domicilio. Esta Garantía es nula si usted ajusta, altera o modifica el producto de cualquier manera. Esta Garantía NO cubre daños que excedan el precio de compra del producto y BAJO NINGUNA CIRCUNSTANCIA COMFORT BILT® SE HARÁ RESPONSABLE DE LOS DAÑOS ACCIDENTALES, ESPECIALES O RESULTANTES CON RESPECTO A FÉRDIDA

ECONÓMICA O LESIÓN PERSONAL O DAÑO DE LA PROPIEDAD VA SEA COMO RESULTADO DEL INCUMPLIMIENTO DE UNA GARANTÍA IMPLÍCITA O EXPRERA, NEGLEGENCIA U OTROS. Algunos estados no permiten la exclusión o limitación de los daños accidentales o resultantes, de modo que la limitación anterior puede que no se aplique en su caso, de forma completa o parcial. CUALQUIER

GARANTÍA IMPLÍCITA DE COMERCIABILIDAD E IDONEIDAD PARA UN FIN EN PARTICULAR QUE SURJA SEGUN LAS LEYES DE CUALQUIER ESTADO ESTÁ LIMITADA EN EL TIEMPO A LA DURACIÓN DE LA COBERTURA PROPORCIONADA EN ESTA GARANTÍA. Algunos estados no permiten limitaciones sobre el tiempo de duración de una garantía implícita, de modo que la limitación antes descrita puede

que no se aplique en su caso. Los términos de esta Garantía no se pueden cambiar excepto que un funcionario de Comfort Bilt® lo haga por escrito. ¿Cómo se relaciona la ley estatal con esta Garantía? Esta

Garantía otorga derechos legales específicos sólo al comprador minorista original, es posible que tenga otros derechos que pueden variar según el estado.