


13

14

- 28

NO.	PARTNAME
1	Index
2	Screw
3	Handle
4	Trim cap
5	O-ring
6	O-ring
7	Cartridge lock nut
8	O-ring
9	Cartridge
10	O-ring
11	O-ring
12	Flow restricter
13	O-ring
14	Aerator
15	Body
16	Copper tube
17	Base
18	Wearing ring
19	Screw
20	Threaded sleeve
21	Gasket assembly
22	Lock nut
23	Screw
24	Flexible hose
25	O-ring
26	Connector
27	Mesh
28	Allen key




SINGLE LEVER LAVATORY FAUCET

The product is CUPC, NSF-61, AB1953, WATERSENSE and ADA certified.

Original certification model code: QE16X02 ASME A112.18.1/CSA B125.1


The tools might be applied to the following places:






VINNOVA


102112-BAF-PC



1. Position the faucet in the installation surface as shown.

2.Adjust the position of the faucet and secure it with the fixing kit as photo.





1. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute. 2. Check all connections at arrows for leaks, re-tighten it if necessary. .

BUT DON'T OVERTIGHTEN

Step 3 Cleaning and care

Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- **2** Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.

3.Connect the flexible hoses to water supply valve (not included) and copper tubes, and tighten it with adjustable wrench. DON'T OVER TIGHTEN!

Caution: make sure connect the hot and cold flexible hose to supply valves correctly.

.

Warning: The supply valves are not included, please purchase them in plumbshop.