

ENJOY LIFE · SHARE HAPPINESS -

INSTRUCTION MANUAL



3PCS Bistro Set SB150J-H01

INTRODUCTION

Thanks for purchasing and trusting NUUGARDEN with your home decorating plans. This product is a furniture designed and made by NUUGARDEN Corp.

We are committed to R&D innovation and creating the most refined, diverse choice of outdoor collection.

After unpacking and before every use, check whether the item shows any damages. In addition, check that you have all parts and hardware before assembly. If there is any damage, please do not use and just call customer service at (800) 257-7108 or send an email to service@nuugarden.com. If you do not have all the parts lists, have your dealer contact us and they will be sent to you immediately.

This furniture is intended for indoor and outdoor use. Please take time to read and follow the instruction below. Use the item as described in this operating manual. We accept no liability for damages caused by improper use.

						Part Number	Images and Sizes	Qty.
						A		1
						В		1
						С		1
			I	M6*28	6	D		1
N	<u> </u>	1	J	M6*32	8	E		4
Р	5	1	К	M6*35	4	F		1
Q		1	L	0	36	G	\bigcirc	1
R		1	М	0)	12	Н	M 6*15	6

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 1

Assemble the back frame (C) to 2 arms (A & B) with 2 washers (L) and 2 bolts (I).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 2

Assemble the seat frame (D) to 2 arms and back frame with 6 washers (L) and 6 bolts (H).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 3

Assemble the base (F) to the seat frame with 4 nuts (M), 8 washers (L) and 4 bolts (I).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 4

Assemble the foot ring (G) to 4 chair legs (E) with 4 washers (L) and 4 bolts (K).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 5

Secure and tighten all the components. Connect the base and chair legs with 8 nuts (M), 16 washers (L) and 8 bolts (J).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 6

Tie the seat cushion (Q) to the seat and put the pillow (R).



Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.





Place the table top (F) upside down on a soft surface. Attach the table legs (G) to the table top (F) by using M8x28 combination hex bolts (EE).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 2

Attach the leg connector (H) to the table legs (G) using M6x15 combination bolts (FF).

Note: Please do not tighten any bolt until all bolts have been put into right place. If you tighten one bolt, it maybe cause other bolts out of position.



STEP 3

Once all of the bolts are in place, fully tighten the bolts. Turn the table right side up. Insert the umbrella ring (I) into the table top (F). Ensure all connections are secure before use.

CARE AND MAINTENANCE

Follow the instruction for the material of your special product to make sure that it stays in the best shape for as long as possible. The information below is only intended as a general guideline. For more information, please contact us.

- Only need to rinse it thoroughly with clean water to wash away dirt and grime. Never use abrasive cleansers on the furniture, since it can attack the surfaces and leave behind scratch marks.
- For the stubborn grime and stains, just use a soft sponge and mild soapy water and then dry it with a cloth or paper towel.
- Check the stability of the screws, nuts and nut caps prior to each use. Tighten up them after one to two month's use whenever required.
- Avoid improper use, and be careful not to scratch or damage the surface with sharp objects.
- When you move your furniture, make sure you lift it rather than pulling or pushing it to avoid damaging the floor, legs and mounting.

CUSTOMER SERVICE

Thanks for purchasing this NUUGARDEN furniture. We are here to help you

maximize your enjoyment and appreciation of it.

Please do not hesitate to contact our customer service when you have any

questions regarding assembly or accessories.

Add: 6366 Corley Road, Norcross, GA 30071.

Tel: (800) 257-7108

Web: http://www.nuugarden.com

E-mail: service@nuugarden.com

Service time: Mon-Fri, 8:30 AM-5:30 PM, EST





Nuu Garden Corp.

Add: 6366 Corley Road, Norcross GA 30071. Tel: (800) 257-7108 Web: http://www.nuugarden.com E-mail: service@nuugarden.com