USER GUIDE





TABLE OF CONTENTS

Box Contents	••••••••••••••••	
Installation	•••••••••••••••••	
SPIRIT II		4
GENESIS II & (GENESIS II LX	
Quick Start Instr	uctions	
Important Information		
Intended Use		
Meat Probe U	se	
Disposal Requ	uirements	
Technical Spe	ecifications	
FCC Complian	1Ce	
IC Compliance	е	



Box Contents





SPIRIT II OLP ONG

Remove cover plate. Some models may have screws.





SPIRIT II OLP NG

Install batteries. Do not mix old and new batteries. Do not mix alkaline, standard or rechargeable batteries.





SPIRIT II OLP NG

Install bracket on the inside of the wheel frame. Snap battery pack into bracket. Connect battery wire to the battery pack.





SPIRIT II OLP NG

Route battery wire through front of side table. Connect battery wire to the iGRILL.







SPIRIT II OLP IG

Install magnet.





SPIRIT II OLP ING

Connect LP fuel sensor.





SPIRIT II OLP NG

Snaps into place. No screws required.



SPIRIT II OLP NG

Remove adhesive liner from wire retention clip. Apply clip to cleansed area underneath side table. Wire(s) must be secured using clip.





Remove cover plate. Some models may have screws - OR -



Remove LED fuel gauge.







GENESIS II

Install batteries. Do not mix old and new batteries. Do not mix alkaline, standard or rechargeable batteries.





GENESIS II OLP ONG

Install bracket underneath side table.





Connect the battery wire to the battery pack. Then, snap the battery pack into the bracket.





GENESIS II OLP NG

Route battery wire through front of side table. Connect battery wire to the iGRILL.





Install magnet on GENESIS II models. GENESIS II LX models already have magnet installed.





Connect LP fuel sensor.





Connect lighted control knob wires. Installation on GENESIS II LX only.





GENESIS II OLP NG

Snaps into place. No screws required.





Remove adhesive liner from wire retention clip. Apply clip to cleansed area underneath side table. Black wire(s) must be secured using clip.







Download the WEBER iGRILL App. Then enable Bluetooth® on your smart device under 'Settings'.





Press the power button once to turn on the iGRILL 3. A single beep will sound.





Open the door on the front of the iGRILL 3 to expose the probe ports.





Plug one or more probes into the ports.



WARNING: Risk of burns!

Handling the meat probes without hand protection will result in severe burns. Please wear heat-resistant gloves or mitts at all times while using this product in order to avoid being burned.





Launch the WEBER iGRILL App on your smart device. Follow the pairing instructions within the app.

You are now ready to use your iGRILL 3.

Additional information, instructional videos and barbecue inspiration can be found at <u>weber.com/igrillsupport</u>.

Important Information

Visit <u>weber.com/igrillsupport</u> to find out more about device compatibility, languages supported by the WEBER iGRILL App, a full user guide with instructional set up videos, and great barbecuing inspiration. Please read the full user guide – especially the safety information – before using the WEBER iGRILL 3 for the first time, and follow the instructions while using the device.

Intended Use

Use this device only for measuring and monitoring the temperature of grilled items on WEBER iGRILL compatible products only. On the GENESIS II LX models, the knob lights can be turned on and off directly from the WEBER iGRILL App. Any use other than that which has been described may cause damage. The manufacturer or retailer are not liable for damages arising from improper use. When using an iGRILL 3, never leave your grill unattented and follow all instructions in your grill owners guide.

Note: The device is not to be used by children or persons with reduced physical, sensory or mental capabilities.

Note: Do not mix old and new batteries. Do not mix alkaline, standard or rechargeable batteries.

Meat Probe Use



WARNING: Risk of injury! The probes are very sharp. Please be careful when handling the probes.

WARNING: Risk of burns! Handling the temperature probes without hand protection will result in severe burns. The coloured probe indicators are not intended to be touched with bare hands while using the barbecue as they are not heat-insulated. Please wear heat-resistant gloves at all times while using this product in order to avoid being burned.

Important Note: When using probes, be sure to route wire where it will not be exposed to flames or temperatures exceeding 716° F (380° C). Avoid exposing probes to temperatures below -22° F (-30° C). Temperatures below -22° F (-30° C) or above 572° F (300° C) will not display in the app and will cause the probe to disappear from connection.

Clean the probes before first use. The probes are not dishwasher safe. Do not use chemicals or abrasive detergents to clean the probes. Wipe down the probes with a damp towel or cleaning wipe. Take care not to expose the probe's wiring or the area where the wiring meets the probe to liquid .

The probes are not waterproof and damage may result from water exposure. Never submerge the probes in water.

Disposal Requirements



WARNING: Battery disposal! Never dispose of batteries in an open fire. Always dispose of batteries in accordance with local laws.

Technical Specifications

Frequency Range (MHz): 2402.0 - 2480.0 MHz

Output Power (Watts): 0.0012 W

FCC Compliance

This equipment has been tested and found to comply with the rules for white space devices, pursuant to part 15 of the FCC rules. These rules are designed to provide reasonable protection against harmful interference. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult the manufacturer, dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by WEBER could void the user's authority to operate this device.

IC Compliance

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.



Importado y Distribuido en México por: Weber-Stephen Products S.A. de C.V.

ANATOLE FRANCE 139-139A Colonia. POLANCO III SECCION Del. MIGUEL HIDALGO CIUDAD DE MEXICO C.P. 11540 RFC: WPR030919-ND4 Teléfono: 01800-00-WEBER (93237)

Imported by / importé par WEBER-STEPHEN (CANADA) COMPANY

1 Roybridge Gate Vaughan, Ontario, CANADA L4H 4E6

The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Weber-Stephen Products LLC is under licence. Other trademarks and trade names are those of their respective owners.



59980_enUS_032019

iGRILL 3 | USER GUIDE 30