REMOTE CONTROL INSTRUCTIONS

NOTE:

Please insert 2 batteries before using. AAA 1.5V battery x 2pcs (not included)

- (1) Turn off the light and fan.
- (2) Turn on/off the light,
- (3) Natural wind mode.
- (4) Turn on/off the mute mode.
- (5) 1/2/3/4/5/6 for Fan speed.
- (6) Turn off the fan (remote signal pairing).
- (7) Fan forward.
- (8) Fan reverse.
- (9) 1H- 4H for timing the fan.

REMOTE SIGNAL PAIRING: If the remote control looses the signal of the fan, turn off the power from wall switch, then turn it on, press (6) immediately for around 3 seconds, after the fixture beeps or flashes, then it's down.



INSTALLATION MANUAL

CEILING FAN WITH LIGHT

Model No.: FS-8837D-72-01

APP CONTROL INSTRUCTIONS

1





Note: Install the "Tiny Smart" app from Google Play, Apple App Store, or other app stores by scanning the QR code or searching for the app name. Ensure that your phone is connected to the internet and Bluetooth enabled.

Pairing: Add device \rightarrow Follow the APP operation to turn off the wall switch, and turn it on after 5 seconds. The device will automatically connect to the Ceiling Fan.

Adjust the level : 5Level	Slide to adjust the Fan Speed.
ON OFF	Turn on/off the light.
ON OFF Electric fan	Turn on/off the fan.
() All Off	Turn off the fan and light.
Timer	1H-8H for timing the fan.
ریے۔ Natural	Natural Wind: Simulate natural wind and automatically adjust the wind speed.
Revers	Fan forward & Fan reverse.







Scan for Installation Video





PACKING LIST





9. Install the Light Kit

Step 1. Connect the Light Wires from the Light Kit to the fixture wires. Step 2. Fix the Light Kit onto the Light Shade (the Nipple passes through the Light Kit).



INSTALLATION KIT





NOTE:

1. Some extra hardware may be included. The quantity listed above is the number required for installation.

2. Parts "GG" have already been installed with Long Downrod Assembly, parts "DD" have been installed with Fan Motor Assembly. They need to be disassembled before installation.

7. Install the Light Shade

Step 1. Take off the Set Screws from the Fan Motor Assembly.

Step 2. Rotate the Light Kit counter clockwise and remove it from the Light Shade. Step 3. Attach the Light Shade onto the Fan Motor Assembly with screws taken off.



8. Attaching the Nipple

Step 1. Attach the Nipple (HH) in the Fan Motor Assembly.



INSTALLATION

1. Installing the Mounting Bracket

Step 1. Take off the screws from outlet box.

Step 2. Secure the mounting bracket (EE) onto the outlet box with screws taken off or Outlet Box Screw With Washer (FF) provided.



2. Assembling the Fan

Step 1. Assemble the Canopy and coupling cover, route wires from the fan through the downrod.
Step 2. Loosen the set screw from the yoke but do not take off, align the holes at the bottom of the downrod with those in the yoke.
Step 3. Carefully insert the clevis pin (GG) through the holes in the yoke and downrod (Be careful not to jam the clevis pin against the wires inside the downrod).
Step 4. Insert the "R" pin (GG) into the end of the clevis pin.
Step 5. Tighten the set screw on the yoke to secure the downrod.



······ Mounting Bracket (EE)

----- Outlet Box Screw With Washer (FF)

3. Hanging the Fan and Locking the Hanging Wire

Step 1. Lift the downrod into the mounting bracket. Rotate the downrod until the seat tab in the mounting bracket is seated in the groove in the downrod ball.

Step 2. Wrap the Hanging Wire around the side of the mounting bracket and thread it through the lock to secure it.

Step 3. Pull on the hanging wire strands to tighten them in place and secure it with screws.

----- Seat Tab Mounting Bracket - · Downrod Ball





4. Wring

Step 1. Insert the receiver to the mounting bracket

Step 2. Connect the wires from the fixture to the house supply wires with wire nuts (AA), ground wire (green, green/yellow, or bare copper) to ground wire, neutral wire (white or blue) to neutral wire, and hot wire (black or brown) to the hot wire.

Step 3. Wrap the connection with electrical tape.





Note:

① This fan only needs one set of input wires (black, white, and ground wire). Both of the fan and lights will be controlled by the remote control. (2) This fan can only be connected to an on/off switch if you have one, not a dimmer switch.

5. Attaching the Canopy

Step 1. Slide the canopy up to the ceiling and attach it to the mounting bracket with the set screws provided. Step 2. Slide the coupling cover downward to cover the yoke and fix the canopy ring to the canopy.



6. Installing the Fan Blade and Blade Arm Step 1. Attach fan blade onto the blade arms with Fan Blade Screws (BB) provided. Step 2. Take off Fan Blade Arm Screws (DD) from the Fan Motor Assembly. Step 3. Attach the Fan Blade Arm onto the motor with the Fan Blade Arm Screws taken off.



Note: 1 Make sure to assemble the blades in sequence and fasten the screws with equal force. Set Screw

----- Canopy Ring

----- Coupling Cover