


INSTALLATION INSTRUCTIONS

DeerValley®

MIRROR CABINET INSTRUCTION MANUAL



INSTALLATION INSTRUCTIONS

The DeerValley logo is located in the top right corner. It consists of the words "DeerValley" in a white, sans-serif font, with a registered trademark symbol (®) to the upper right of the "y". The logo is set against a dark grey rectangular background.

GENERAL INFORMATION

- Mirror products are extremely fragile, please transport and handle with care.
- This product should be installed by a licenced electrician.
- Ensure the main power is off before installation.
- Do not install within 23.6" of direct wet area contact. (ie. 23.6" from bath or open shower)

To electrician:

Please ensure a copy of the product instruction manual is left with the end user for future reference.

Thank you for purchasing our mirror products, we hope you and your family enjoy our new product and consider us for any future project. All of our products have been manufactured under the highest standards of quality and workmanship.

**If you have any questions or concerns
please contact us:**

(+1) 312-626-9466
service@deervalleybath.com

TOOL



PRODUCT




&




INSTALLATION


1. Measure the position of the back mount.



- 2.



3. Insert the expansion sleeve into the hole.



- 4.

This product is manufactured to class I category and must have an earth connection.

Color coding:


L - Live = Black
N - Neutral = White
⊕ - Earth = Green

Strip wires to a suitable length.
DO NOT connect to a plug
& socket outlet.




IF IN DOUBT, CONSULT YOUR ELECTRICIAN

5. Fixing screw with screw cover.



- 6.

Ensure the mirror cabinet is securely hung.




Drawings may not exactly define contour of the product.

WARNING

Make sure the wires are connected correctly.

OPERATION INSTRUCTION

Touch Switch



Single touch ☀ to turn on. Single touch to switch color temperature, long press to adjust brightness. After 3 seconds of no operation, single touch ☀ to turn off.
Single touch 🌊 to activate the demisting function.

Drawings may not exactly define contour of the product.

MAINTENANCE AND CLEANING RECOMMENDATION

To avoid damage and optimize your product, please do not use anything abrasive to clean the surface. Cleaning it by rinsing with clean water and drying with a soft cotton cloth or sponge. Clean regularly to prevent the accumulation of dirt and tough stains.

LIMITED WARRANTY COVERAGE

1 YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide the customers a long-lasting product. In the case of any defects in materials or craftsmanship under regular use were inspected in the first one year of delivery, DeerValley will provide replacement parts at no charge, or at its option, replace any product or part of the product that is deemed defective, under normal installation, use, service and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required in the case of a claim. **SCRATCHES ARE NOT COVERED UNDER WARRANTY.**

The manufacturer warrants this product to be free of manufacture defects during the above mentioned warranty time. Please keep a copy of the original invoice as proof of purchase.

DeerValley will, as its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund of the original purchase price of the product(s) (Valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product shipping/delivery charges may apply and are in DeerValley sole discretion.

DeerValley recommends the installations to be made by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to use a licensed professional. DeerValley is not responsible for any removal or installation cost.

This limited warranty shall not apply to goods which have been subject to accident, negligence, improper installation, product abuse, product misuse, or use of cleaners containing abrasives, alcohol or other organic solvents, whether performed by a contractor, service company, or yourself, are excluded from this warranty.

DeerValley responsibility under this limited warranty is limited to only to replacement parts and no other costs. DeerValley will not be responsible for labor charges and/or damage incurred by installation, repair or replacement, nor for any indirect incidental or consequential damages, losses, injury or costs of any nature relating to this product Except as provided by law, this limited warranty is in lieu of and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including without restriction those merchantability of fitness for use.

RESPONSIBILITIES OF OTHERS

Inspecting the unit prior to installation is the responsibility of the installer or building contractor who acts on behalf of the user. They are responsible for ensuring the unit is free of defect or damage.

Notices are placed on and in the unit and on the shipping carton advising the installer of this responsibility.

In the event of a problem, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been discovered, repaired, or avoided by proper inspection and testing prior to installation.

Damage occurring in transit is the responsibility of the carrier. The user or installer **MUST** open the crate and inspect the unit for damage when it is delivered. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection requested. Failure of the carrier to respond should be reported to the seller and the carrier. Your freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover instances of negligence, misuse, abuse, improper installation, carelessness, accident, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages caused by improper maintenance, alteration of the product, or failure to follow care or installation instructions enclosed with your product. The warranty becomes invalid if the DeerValley product undergoes any alterations or if attempts are made to carry out repairs using unauthorized accessories or parts from DeerValley.

DeerValley will not be liable for loss of use of the DeerValley products, inconvenience, or any other incidental or consequential costs, expense or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly provided, there shall be no warranty or obligation, express or implied, oral or statutory. No dealer or other person has the authority to make any warranties or representations concerning DeerValley or its products. In no event shall DeerValley be held responsible for any such warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty, be sure to have the following:

- Copy of original invoice
- Date of installation
- Description and pictures of defect
- Model number or description of model

To obtain warranty service and replacement part, please contact DeerValley Customer Service. DeerValley will determine whether to repair or replace your product, issue a refund, or issue a credit.