


OWNER'S MANUAL



Multifunction adirondack chair

**QUESTIONS? NEED PARTS?
WE ARE HERE TO HELP!**

Please feel free to contact us. There are no questions too small, or any problems too big. We're committed to providing our customers with the highest level of service.






























Customer Service


EMAIL: KINGYES@patioadirondack.com

PARTS LIST

Multifunction adirondack chair should include the following parts. Please inspect box contents to ensure you have received all components.

If you are missing any parts, need assistance with assembly or have questions, please contact our Customer Service: KINGYES@patioadirondack.com

(A)		1pc	(1)	M6*40mm 	2pcs
(B)		1pc	(2)	M6*50mm 	4pcs
(C)		1pc	(3)	M6*60mm 	4pcs
(D)		1pc	(4)	M6*30mm 	2pcs
(E)		1pc	(5)	M6*50mm   	2pcs
(F)		1pc	(6)	M6*60mm   	6pcs
(G)		1pc	(7)	M6*80mm   	2pcs
(H)		1pc	(8)		1pc
(I)		2pcs	(9)		1pc
(J)		1pc			
(K)		1pc			
(L)		1pc			
(M)		1pc			
(N)		1pc			




ASSEMBLY INSTRUCTIONS




Do not overtighten screws. (Insert all screws before tighten screws)

STEP 1




⑥ x2

STEP 2




④ x2

STEP 3



⑥ x2

STEP 4




⑦ x2

ASSEMBLY INSTRUCTIONS




Do not overtighten screws. (Insert all screws before tighten screws)


STEP 5



STEP 6




STEP 7



Warning:

Do not place wine glasses, water glasses or mobilephone when shaking the chair to avoid slipping or spilling.



Warning:

1. Please plug the chain bolt to fix the seat before using!
2. Please unplug the chain bolt before folding!



ASSEMBLY INSTRUCTIONS



Do not overtighten screws. (Insert all screws before tighten screws)


Warning:

1. Please plug the chain bolt to fix the seat before using!
2. Please unplug the chain bolt before folding!




Warning:

Do not place wine glasses, water glasses or mobilephone when shaking the chair to avoid slipping or spilling.



Warning:

Do not place wine glasses, water glasses or mobilephone when shaking the chair to avoid slipping or spilling.



WARNINGS

1. **Read and understand all instructions.** Failure to follow all instructions may result in injury and/or damage.
2. **The warnings, cautions, and instructions discussed in this manual cannot cover all possible conditions or situations that may occur.** The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.
3. **Do NOT modify the product in any way.** Unauthorized modification may impair the function and/or safety of the product, and may affect the life of the product. Any modifications will void warranty.
4. **Check for damaged parts.** Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.
5. **Do NOT overload the product.**

Total weight capacity	350 lb (evenly distributed)
-----------------------	-----------------------------

6. **Do NOT sit on the armrest or backrest.** Tipping may occur causing injury.
7. **Do NOT allow children to climb onto or hang from backrest.** Tipping may occur causing injury.
8. **This is made with UV-stabilizers to minimize fading, however, upon exposure to the sun, all colors will fade to some degree.** To minimize possible fading: keep product covered, utilize cushions where applicable, minimize direct sunlight by storing product when not in use, or use a UV-protectant.

CARE AND MAINTENANCE

- Avoid harsh, abrasive cleaners, and other corrosive chemicals.
- Do not use metal scouring pad for cleaning. Most stains can be removed by using a mild soap and a soft-bristled brush.
- Avoid placing any direct heat source on or near the surface.
- Leaving any glassware on Chair under sunlight may result in burn marks on the surface. Please use a coaster when placing glassware on Chair .