



PORTFOLIO® and PORTFOLIO & Design™ are trademarks or registered trademarks of LF, LLC. All rights reserved.


ITEM #0616075

MOTION-ACTIVATED WALL SCONCE

MODEL #WS146W

Français p. 7

Español p. 13



ATTACH YOUR RECEIPT HERE

Serial Number _____ **Purchase Date** _____




Questions, problems, missing parts? Before returning to your retailer, call our customer service department at **1-800-643-0067**, 8 a.m. - 6 p.m., EST, Monday - Thursday, 8 a.m. - 5 p.m., EST, Friday.

PACKAGE CONTENTS

PART	DESCRIPTION	QUANTITY
A	Fixture	1

A




HARDWARE CONTENTS (shown actual size)

AA



Fixture Screw

BB



Plastic Anchor

SAFETY INFORMATION

READ AND SAVE THESE INSTRUCTIONS.

CAUTION

- Do NOT tamper with or attempt to repair LED component of fixture. The light source is designed for this specific application and should not be serviced by untrained personnel. If any servicing is required, call our customer service department.
- When disposing of household alkaline batteries, it is best to check with your local and state recycling or household hazardous waste coordinators concerning the specifics of the program in your area. You may also locate a recycling center by calling 1-877-723-1297 or 1-877-2-RECYCLE (1-877-273-2925) or visiting www.call2recycle.org for more information.
- When installing (or replacing) batteries, do NOT mix different types of batteries.
- Do NOT mix old and new batteries; when replacing one battery, replace all four of them.
- For best results, install fixture at least 1 in. above the ground/floor.
- For Indoor Use Only -- NOT FOR OUTDOOR USE

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 - 15 minutes


Tools Required for Assembly (not included): Phillips Screwdriver, Drill, 1/8 in. Drill Bit, Hammer, Safety Glasses, Pencil

Helpful Tools (not included): Stepladder

ASSEMBLY INSTRUCTIONS


1. Determine the approximate location for the fixture (A). Place fixture (A) against the wall and mark the location of the hole using a pencil or a marker (not included).

Set fixture (A) aside. Then, using a 1/8 in. drill bit (not included), drill a pilot hole at the marked location. Position plastic anchor (BB) in the pilot hole. Gently tap plastic anchor (BB) with a hammer (not included) until flush with wall surface.



2. Remove battery cover from back of fixture (A). Install four AA batteries (not included). Observe diagram inside battery compartment to install batteries correctly according to polarity.


Replace battery cover.



ASSEMBLY INSTRUCTIONS

- Screw fixture screw (AA) into plastic anchor (BB), allowing about one thread of the screw to remain showing.


Hang fixture (A) on fixture screw (AA).




OPERATING INSTRUCTIONS

- The fixture (A) can be used as a motion-activated light or a touch light, depending on the setting chosen. There are four different settings on the backside of the fixture (A) -- settings are as follows:


1a. **OFF** Light is OFF




1b. **10S** Light turns on when motion is detected, stays on for 10 seconds, then turns off [NOTE: It must be dark for light to operate in this setting]



1c. **60S** Light turns on when motion is detected, stays on for 60 seconds, then turns off [NOTE: It must be dark for light to operate in this setting]



1d. **TOUCH ON/OFF** Light works by touch to turn ON, to cycle through brightness levels (LOW, MED, MED-HI and HI) and then to turn OFF




OPERATING INSTRUCTIONS

2. The front of the fixture (A) has a motion sensor in the middle and two touch sensors, one either side.


2a. **Notes on MOTION Sensor:**

- Detects motion up to 18 in. away and within a 120° radius.
- Works only when there is enough darkness.
- Only functional on the **10S** and **60S** settings.



2b. **Notes on TOUCH Sensors:**

- Tapping either touch sensor once turns light ON; each subsequent tap cycles through the brightness levels (from LOW to MED to MED-HI to HI) and then OFF.
- Brightness levels (LOW, MED, MED-HI and HI) may be adjusted on all settings (except for "OFF") by tapping one of the touch sensors.
- Auto-resume capability keeps light at same brightness level as the last time it was turned off.



CARE AND MAINTENANCE

- Wipe fixture with soft, damp cloth. Use window cleaner to clean glass. Do not use an abrasive cleaner on glass or fixture.
- Bulb Information: The total wattage for this item is 1 watt. **NOTE:** The LEDs and LED components are not replaceable.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Light does not come on initially or no longer comes on.	<ol style="list-style-type: none">1. Setting is in OFF position.2. The ends of one or more batteries are not making contact with the terminals.3. Batteries are old.4. LED component is not working properly.5. Fixture does not come on right away.	<ol style="list-style-type: none">1. Make sure fixture is set to one of the three "on" settings.2. Remove batteries and wipe ends of batteries with a cloth. Re-install batteries and check to make sure both ends of batteries are making contact with the terminals.3. Replace all batteries with new batteries.4. Contact customer service.5. Allow 10 seconds for fixture to reset after inserting batteries or changing settings.

WARRANTY

The distributor warrants all of its lighting fixtures against defects in materials and workmanship for five (5) years from the date of purchase. If within this period the product is found to be defective, take a copy of the bill of sale as a proof of purchase and the product in its original carton to the place of purchase. The distributor will, at its option, repair, replace or refund the purchase price to the consumer. All costs of installation and removal of the fixture is the responsibility of the consumer. This warranty does not cover fixtures becoming defective due to misuse, accidental damage or improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages. As some states do not allow exclusions of limitations on an implied warranty, the above exclusion and limitation may not apply. This warranty gives you specific rights and you may also have other rights which may vary from state to state.