



ITEM #0174350  
**STEEL WOVEN CHAIR**

MODEL # LGD-1087-C


**Française p.5**

**Español p.9**



Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-643-0067, 8 a.m. – 8 p.m., EST, Monday – Friday.

**PACKAGE CONTENTS**



Part	Description	Quantity
A	Lumbar Pillow	1
B	Seat Bucket	1
C	Base	1

**HARDWARE LIST**

Part	Description	Quantity	Picture
AA	Bolt (1/4 in. - 20 x 0.591 in. L)	2	
BB	Bolt (1/4 in. - 20 x 1.181 in. L)	2	
CC	Washer	4	
DD	Bolt Cover	4	
EE	Hex Wrench	1	

**SAFETY INFORMATION**

- Read these instructions carefully before assembly.
- It takes two people to assemble this product.
- Paint on this furniture might peel if it is not handled properly. Handle it with care.


**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and diagram. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

Estimated Assembly Time: 20 minutes  
 Tools Required for Assembly: Hex Wrench (provided)

**ASSEMBLY INSTRUCTIONS**


- Put the seat bucket (B) upside down on a soft surface such as carpet. Assemble base (C) to the front side underneath seat bucket (B) using bolt (BB) and washer (CC). Don't tighten the bolts at this time. Repeat the above step on the other side of the seat bucket.



**HARDWARE LIST**

Part	Description	Quantity	Picture
BB	Bolt (1/4 in. - 20 x 1.181 in. L)	2	
CC	Washer	2	
DD	Bolt Cover	2	
EE	Hex Wrench	1	

- Connect the back underneath seat bucket (B) using bolts (AA) through the holes on back (B) and rear legs of base (C). Again, don't tighten the bolts completely. Check alignment of all hardware and make corrections if necessary. Fasten all bolts tightly with hex wrench (EE) provided. Cover all bolts with bolt covers (DD).



**HARDWARE LIST**

Part	Description	Quantity	Picture
AA	Bolt (1/4 in. - 20 x 0.591 in. L)	2	
CC	Washer	2	
DD	Bolt Cover	2	

**CARE AND MAINTENANCE**

- Clean frame with a solution of warm water and mild soap. Dry completely. Do not use bleach or solvents. Use a fine automotive wax to maintain gloss on non-textured finishes.
- Severe stains may require light sanding and touch-up painting.
- When using touch-up paint, if covering scratches, rub lightly with fine steel wool to smooth the surface and improve paint adhesion. Apply thin coats of touch-up paint and allow ample drying time between coats.
- The finish on furniture is formulated and baked on to make it highly resistant to repellents and lotions. However, to avoid discoloration, clean the frame as soon as possible after exposure.
- For best results, clean weave regularly with mild detergent and warm water. Cleaning will help prevent mildew by washing out dirt particles that may become trapped. Shake out excess moisture after rinsing and allow to dry thoroughly before storing.

**ONE-YEAR LIMITED WARRANTY**

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture, provided your furniture is maintained with care and used only for personal, residential purposes. Frames and welds are warranted to be free from defects in material or workmanship for a period of one (1) year.

Finish is warranted against peeling, cracking or blistering for a period of one (1) year. Weave is warranted to be free from defects in workmanship for a period of one (1) year. Exclusions: Items used for commercial, contract or other non-residential purposes; display models; items purchased "as is;" or items damaged due to acts of nature, vandalism, misuse or improper assembly are not covered. Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills; tabletop breakage; corrosion or rusting of hardware; and damages to frames or welds caused by improper assembly, misuse or natural causes are not covered.

If within the stated warranty period a product is found to be defective in material or workmanship, the purchaser must contact the manufacturer's customer service department at 1-800-643-0067. The manufacturer, at its option, will repair or replace the defective parts.

The warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

**REPLACEMENT PARTS LIST**

For replacement parts, call our customer service department at 1-800-643-0067, 8 a.m. – 8 p.m., EST, Monday – Friday.

Part	Description	Part#
GG	Foot Glide	LG1087-3000-18

