

SERVICE INFORMATION

All Black & Decker Service Centers are staffed with trained personnel to provide customers with efficient and reliable power tool service. Whether you need technical advice, repair, or genuine factory replacement parts, contact the Black & Decker location nearest you. To find your local service location, refer to the yellow page directory under "Tools—Electric" or call: **1-800-544-6986** or visit www.blackanddecker.com

 **WARNING:** Tool service must be performed only by qualified repair personnel.

 **WARNING:** When servicing a tool, use only identical replacement parts.

WARRANTY

Full Two-Year Home Use Warranty

Black & Decker (U.S.) Inc. warrants this product for two years against any defects in material or workmanship. The defective product will be replaced or repaired at no charge in either of two ways.

The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges (usually 30 to 90 days after the sale). Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges.

The second option is to take or send the product (prepaid) to a Black & Decker owned or authorized Service Center for repair or replacement at our option. Proof of purchase may be required. Black & Decker owned and authorized Service Centers are listed under "Tools-Electric" in the yellow pages of the phone directory.

This warranty does not apply to accessories. This warranty gives you specific legal rights and you may have other rights which vary from state to state or province to province. Should you have any questions, contact the manager of your nearest Black & Decker Service Center. This product is not intended for commercial use.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, check country specific warranty information contained in the packaging, call the local company or see the website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call **1-800-544-6986** for a free replacement.

TROUBLESHOOTING

Problem	Possible Cause	Possible Solution
<ul style="list-style-type: none"> Material runs or drips 	<ul style="list-style-type: none"> Spraying too much material. 	<ul style="list-style-type: none"> Reduce air flow by turning flow control knob.
<ul style="list-style-type: none"> Too much over spray. 	<ul style="list-style-type: none"> Spraying too slowly. Spraying too close. Viscosity too thin. Sprayer too far from surface. Too much material being sprayed. 	<ul style="list-style-type: none"> Increase speed of application. Increase distance from surface. Check dilution recommendation. Reduce distance to surface. Reduce air flow by turning flow control knob.
<ul style="list-style-type: none"> Little or no material being released. 	<ul style="list-style-type: none"> Check valve ball stuck. 	<ul style="list-style-type: none"> Remove check valve. Depress ball to loosen. Add lubricant. See figure Q.
<ul style="list-style-type: none"> Material being sprayed is splattering. 	<ul style="list-style-type: none"> Spray nozzle/tip clogged. Pickup tube loose or clogged. Air hose split or disconnected. Flow control knob setting too low. Air inlet blocked. Material too thick. Viscosity of material is too high. 	<ul style="list-style-type: none"> Clean nozzles. Check tube. Check air hose. Increase flow control setting. Clean or change air filter. Check viscosity recommendation. Thin material per manufacturer recommendation.
<ul style="list-style-type: none"> Sprayer pulsates. 	<ul style="list-style-type: none"> Air filter clogged. 	<ul style="list-style-type: none"> Clean or change filter.
<ul style="list-style-type: none"> Liquid comes out side of canister. 	<ul style="list-style-type: none"> Material in canister almost empty. Lid not on square or tight enough. 	<ul style="list-style-type: none"> Refill canister. Remove lid and reattach squarely and evenly, then tighten lid securely.
<ul style="list-style-type: none"> Cannot depress trigger to start spraying. 	<ul style="list-style-type: none"> Paint on threads of canister and lid. Flow control setting is set completely to the minimum side. 	<ul style="list-style-type: none"> Clean threads on top and sides of canister and lid. Back the flow control knob off (clockwise) to allow for more trigger travel.

For assistance with your product, visit our website www.blackanddecker.com for the location of the service center nearest you or call the BLACK & DECKER help line at 1-800-544-6986.

Imported by
Black & Decker (U.S.) Inc.,
701 E. Joppa Rd.
Towson, MD 21286 U.S.A.



See 'Tools-Elec-
tric'
– Yellow Pages –
for Service &
Sales

