

# Use and Care Manual

## 1. Introduction

Thank you for purchasing the Upgraded Wicker Hanging Porch Swing. This swing is designed to provide a comfortable and relaxing experience for up to three adults, with a weight capacity of 900 lbs. It features durable wicker construction, comfortable cushions, an 8.9ft hanging chain, and convenient cup holders.

## 2. Safety Instructions

- **Maximum Weight Capacity:** 900 lbs. Do not exceed this weight limit.
- **Installation Location:** Ensure the swing is installed on a sturdy, level surface. The mounting structure (beam or ceiling) must be able to support the weight of the swing plus occupants.
- **Regular Inspections:** Periodically check all hardware and the swing chains for wear and tear. Replace any damaged parts immediately.
- **Use Caution:** Do not stand on the swing. Always sit properly with both feet on the ground.

- **Supervision:** Children should use the swing under adult supervision.

### 3. Care and Maintenance

- **Cleaning:**

- Wipe down the wicker with a damp cloth and mild soap solution.

Avoid using harsh chemicals or abrasive cleaners.

- Clean the cushions with a fabric cleaner or a mild soap solution.

Allow to air dry completely before use.

- **Weather Protection:**

- When not in use, protect the swing from harsh weather conditions by using a weatherproof cover or storing it indoors.

- During winter or extended periods of non-use, consider disassembling the swing and storing it in a dry, sheltered location.

- **Routine Checks:**

- Inspect the swing monthly for signs of wear, especially the chains and hardware. Tighten any loose bolts and replace any worn parts.

Thank you for choosing our Upgraded Wicker Hanging Porch Swing. We hope it brings you many moments of relaxation and

enjoyment.

## **4. Contact Information**

For assembly assistance, parts replacement, or warranty claims,  
please contact: [service@denislawn.com](mailto:service@denislawn.com)