

immediately afterward as follows:
Release bail handle (2) to turn mower
off and unplug mower. Wipe all exposed
parts with a damp cloth.

⚠ CAUTION: DO NOT POUR OR
SPRAY WATER ON THE MOWER IN AN
ATTEMPT TO CLEAN IT. Do not store the
tool on or adjacent to fertilizers or chemicals.
Such storage can cause rapid corrosion.

MEETS CPSC SAFETY REQUIREMENTS

BLACK+DECKER Mowers conform to
the safety standards of the American
National Standards Institute, and
the U.S. Consumer Product Safety
Commission. The Blade turns when the
motor is running.

MAINTENANCE

IMPORTANT: To assure product
SAFETY and RELIABILITY, repairs,
maintenance and adjustment (including
brush inspection and replacement) should
be performed by BLACK+DECKER
Service Centers or other qualified
service organizations, always using
BLACK+DECKER replacement parts.
When servicing use ONLY IDENTICAL
REPLACEMENT PARTS.

ACCESSORIES

RECOMMENDED ACCESSORIES
FOR USE WITH YOUR MOWER ARE
AVAILABLE FROM YOUR LOCAL
DEALER OR AUTHORIZED SERVICE
CENTER. IF YOU NEED ASSISTANCE
REGARDING ACCESSORIES, PLEASE
CALL: 1-800-544-6986

⚠ WARNING: The use of any
accessory not recommended for use with
this tool could be hazardous.

SERVICE INFORMATION

All BLACK+DECKER Service Centers
are staffed with trained personnel to
provide customers with efficient and
reliable power tool service. Whether you
need technical advice, repair, or genuine
factory replacement parts, contact the
BLACK+DECKER location nearest you.
To find your local service location, call:
1-800-544-6986 or visit
www.blackanddecker.com

Limited Two-Year Home Use Warranty

Black & Decker (U.S.) Inc. warrants
this product for two years against any
defects in material or workmanship.
The defective product will be replaced
or repaired at no charge in either of two
ways.

The first, which will result in exchanges
only, is to return the product to the
retailer from whom it was purchased
(provided that the store is a participating
retailer). Returns should be made within
the time period of the retailer's policy for
exchanges (usually 30 to 90 days after
the sale). Proof of purchase may be
required. Please check with the retailer
for their specific return policy regarding
returns that are beyond the time set for
exchanges.

The second option is to take or send the
product (prepaid) to a BLACK+DECKER
owned or authorized Service Center for
repair or replacement at our option. Proof
of purchase may be required.

This warranty does not apply to
accessories. This warranty gives you
specific legal rights and you may have
other rights which vary from state to state
or province to province. Should you have
any questions, contact the manager of
your nearest BLACK+DECKER Service
Center. This product is not intended for
commercial use.

FREE WARNING LABEL REPLACEMENT: If
your warning labels become illegible or
are missing, call 1-800-544-6986 for a
free replacement.

LATIN AMERICA: This warranty does
not apply to products sold in Latin
America. For products sold in Latin
America, check country specific warranty
information contained in the packaging,
call the local company or see the website
for warranty information.

Imported by
Black & Decker (U.S.) Inc.,
701 E. Joppa Rd.
Towson, MD 21286 U.S.A.

