



Cabinet





IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


















Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools





When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

<p>A x 35</p>  <p>Ø 6 x 35 mm</p>	<p>B x 35</p>  <p>Ø 15 x 10 mm</p>	<p>C x 28</p>  <p>Ø 6 x 30 mm</p>	<p>D x 4</p>  <p>Ø 6 x 50 mm</p>	<p>E x 9</p>  <p>Ø 4 x 35 mm</p>
<p>F x 4</p>  <p>Ø 4 x 25 mm</p>	<p>G x 60</p>  <p>Ø 4 x 12 mm</p>	<p>H x 2</p>  <p>Ø 4 x 12 mm</p>	<p>J x 56</p>  <p>Ø 2 x 10 mm</p>	<p>K x 5</p> 
<p>L x 10</p>  <p>Ø 4 x 12 mm</p>	<p>M x 2</p> 	<p>N x 12</p>  <p>Ø 3 x 10 mm</p>	<p>Q x 2</p>  <p>Ø 4 x 40 mm</p>	<p>R x 2</p>  <p>Ø 6 x 30 mm</p>
<p>U x 10</p> 	<p>V x 2</p> 			




⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*




Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




STEP 1: Extend Slide
Extender la diapositiva
Extendre la diapositive







STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier





STEP 3: Remove Runner
Quitar el corredor
Enlever le coureur




1

<p>A x 2</p>  <p>Ø 6 x 35 mm</p>	<p>B x 2</p>  <p>Ø 15 x 10 mm</p>	<p>C x 4</p>  <p>Ø 6 x 30 mm</p>	
---	--	---	---

Insert quickfit screw(A) into plate 9 with a screwdriver as shown.



Knock wooden dowel(C) into plate 9, then attach plate 10 and 11 to. Add cam lock(B) into plate 10 and 11, turn clockwise to tighten as shown.




2


F x 4







Ø4 x 25 mm





Fix plate 12 to plate 11 with screw(F) as shown.




3

<p>A x 12</p>  <p>Ø6 x 35 mm</p>	<p>M1 x 2</p> 	<p>N x 6</p>  <p>Ø3 x 10 mm</p>	
---	---	--	---





Insert quickfit screw(A) into plate 3 and 4 with a screwdriver as shown.





Fix slide rail(M1) to plate 3 and 4 with screw(N) as shown.


4

B x 12

 Ø 15 x 10 mm

C x 12

 Ø 6 x 30 mm






Knock wooden dowel(C) into plate 9, 10, 11, 8 and 14 at first, then connect with plate 3 and 4.





Add cam lock(B) and turn clockwise to tighten as shown.

5




Insert quickfit screw(A) into plate 1 and 2 with a screwdriver as shown.




6




<p>B x 8</p>  <p>Ø15 x 10 mm</p>	<p>C x 8</p>  <p>Ø6 x 30 mm</p>	
---	--	---




Knock wooden dowel(C) into plate 6 at first,
then connect with plate 1 and 2.
Add cam lock(B) into plate 6 and turn
clockwise to tighten as shown.



7



Insert quickfit screw(A) into plate 5 and 7 with a screwdriver as shown.



8

B x 4



Ø 15 x 10 mm

C x 4




Ø 6 x 30 mm

D x 4




Ø 6 x 50 mm

E x 4





Ø 4 x 35 mm



Knock **SHORT** wooden dowel(C) into plate 5 at first, then attach to the top, turn cam lock(B) clockwise to tighten as shown.

Knock **LONG** wooden dowel(D) into plate 7 at first, then attach to the bottom, and fix with screw(E) as shown.




9



B x 4



Ø15 x 10 mm



Connect the two components, add cam lock(B) into plate 3,4 and turn clockwise to tighten as shown.




10



J x 56



Ø2 x 10 mm




Fix back plate 18, 19, 20 and 21 to the cabinet with screw(J) as shown.





11


A x 5



Ø6 x 35 mm



Insert quickfit screw(A) into plate 15 as shown.



12



M2 x 2




N x 6



Ø3 x 10 mm



Fix runner(M2) to plate 23 and 24 with screw(N) as shown.




13

B x 5







Ø15 x 10 mm


E x 5





Ø4 x 35 mm




Attach plate 23, 25 and 24 to plate 15, turn cam lock(B) clockwise to tighten as shown.



Slide plate 26 along grooves at first.



Fix plate 22 to plate 25, 23 and 24 with screw(E) as shown.



14


K x 1




L x 2



Ø4 x 12 mm




Fix handle(K) to drawer face plate with screw(L) as shown.



15

Align rails, slide the drawer in.



18/22

16

G x 20



Ø4 x 12 mm

K x 4






L x 8




Ø4 x 12 mm

U x 10



Fix hinge(U) to plate 13, 16 and 17 with screw(G) as shown.
Fix handle(K) to door plate with screw(L) as shown.





17


G x 40



Ø4 x 12 mm



Attach door plate 13 to upper cabinet by fixing hinge with screw(G) as shown.



Attach door plate 16 and 17 to lower cabinet by fixing hinge with screw(G) as shown.


18

H x 2




Ø4 x 12 mm

V x 2




Fix part(V) to plate 5 with screw(H) as shown.



19


Q x 2






R x 2



Ø6 x 30 mm



Install anti-tipping device as shown.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.



DEFECTIVE ITEMS


- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.



Cabinet






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

<p>A x 59</p> <p>Ø 6 x 35 mm</p>	<p>B x 59</p> <p>Ø 15 x 10 mm</p>	<p>C x 36</p> <p>Ø 6 x 30 mm</p>	<p>D x 12</p> <p>Ø 6 x 50 mm</p>	<p>E x 31</p> <p>Ø 4 x 35 mm</p>
<p>F x 5</p> <p>Ø 4 x 25 mm</p>	<p>G x 84</p> <p>Ø 4 x 12 mm</p>	<p>H x 2</p> <p>Ø 4 x 12 mm</p>	<p>J x 85</p> <p>Ø 2 x 10 mm</p>	<p>K x 9</p>
<p>L x 18</p> <p>Ø 4 x 12 mm</p>	<p>M x 6</p>	<p>N x 36</p> <p>Ø 3 x 10 mm</p>	<p>Q x 2</p> <p>Ø 4 x 40 mm</p>	<p>R x 2</p> <p>Ø 6 x 30 mm</p>
<p>S x 4</p>	<p>T x 12</p>	<p>U x 10</p>	<p>V x 2</p>	




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*




Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




STEP 1: Extend Slide
Extender la diapositiva
Extendre la diapositive



STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier





STEP 3: Remove Runner
Quitar el corredor
Enlever le coureur




1





A x 12
Ø6 x 35 mm





Insert quickfit screw(A) into plate 7, 2 and 1 with a screwdriver as shown.



2


<p>B x 4</p>  <p>Ø 15 x 10 mm</p>	<p>C x 6</p>  <p>Ø 6 x 30 mm</p>	<p>F x 5</p>  <p>Ø 4 x 25 mm</p>	
--	---	---	---




Knock wooden dowel(C) into plate 7, then attach plate 15 and 16 to.

Add cam lock(B) into plate 15,16 and turn clockwise to tighten as shown.


Fix plate 17 to plate 16 with screw(F) as shown.



3



Fix slide rail(M1) to plate 8 and 9 with screw(N) as shown.




4

C x 4







Ø6 x 30 mm


E x 4






Ø4 x 35 mm




Knock wooden dowel(C) into plate 8 and 9, then attach to plate 7 and fix with screw(E) as shown.



5




Insert quickfit screw(A) into plate 12 and 13 with a screwdriver as shown.




6

<p>B x 8</p>  <p>Ø15 x 10 mm</p>	<p>C x 8</p>  <p>Ø6 x 30 mm</p>	
---	--	---





Knock wooden dowel(C) into plate 7, 15 and 16 at first, then connect with plate 12 and 13.


Add cam lock(B) and turn clockwise to tighten as shown.



7





Knock LONG wooden dowel(D) into plate 11 at first, then connect with plate 3 and 4 and fix with screw(E) as shown.





8

<p>B x 8</p>  <p>Ø 15 x 10 mm</p>	<p>C x 4</p>  <p>Ø 6 x 30 mm</p>	
--	---	---



Knock wooden dowel(C) into plate 3 and 4 at first, then attach plate 10 to. Add cam lock(B) into plate 10 and turn clockwise to tighten as shown.



9




<p>B x 8</p>  <p>Ø 15 x 10 mm</p>	<p>C x 8</p>  <p>Ø 6 x 30 mm</p>	
--	---	---

Knock wooden dowel(C) into plate 1 and 2 at first, then attach to plate 10.




Add cam lock(B) into plate 10 and turn clockwise to tighten as shown.

10



Insert quickfit screw(A) into plate 5 with a screwdriver as shown.



11

B x 8








Ø 15 x 10 mm



C x 8



Ø 6 x 30 mm






Knock wooden dowel(C) into plate 1, 2, 3 and 4 at first, then attach plate 5 to.




Add cam lock(B) into plate 1,3,4,2 and turn clockwise to tighten as shown.

12



Insert quickfit screw(A) into plate 6 with a screwdriver as shown.




13

D x 8







Ø6 x 50 mm


E x 8



Ø4 x 35 mm



Knock LONG wooden dowel(D) into plate 1, 3, 4 and 2 at first, then attach plate 6 to and fix with screw(E) as shown.





14


B x 8



Ø15 x 10 mm



Connect the two components, add cam lock(B) into plate 12,8,9,13 and turn clockwise to tighten as shown.




15


J x 85





Ø2 x 10 mm





Fix back plate 20, 21, 30 and 31
to the cabinet with screw(J) as shown.



16






Insert quickfit screw(A) into plate 27 as shown.





x3

17



Fix runner(M2) to plate 23 and 24 with screw(N) as shown.



x3


18

B x 15






Ø 15 x 10 mm

E x 15






Ø 4 x 35 mm



Attach plate 23, 25 and 24 to plate 27, turn cam lock(B) clockwise to tighten as shown.

Slide plate 26 along grooves at first.



Fix plate 22 to plate 25, 23 and 24 with screw(E) as shown.

19


K x 3




L x 6




Ø4 x 12 mm








Fix handle(K) to drawer face plate with screw(L) as shown.



20




Align rails, slide the drawer in.





21






T x 12






Insert part(T) into plate 3, 4, 12, 8, 9 and 13, then place shelf 14 and 34 in as shown.







22

<p>G x 24</p>  <p>Ø 4 x 12 mm</p>	<p>K x 4</p> 	<p>L x 8</p>  <p>Ø 4 x 12 mm</p>	<p>U x 10</p> 	
--	--	---	--	---






Fix hinge(U) to plate 18, 28 and 29 with screw(G) as shown.




Fix handle(K) to door plate with screw(L) as shown.




23


<p>G x 8</p>  <p>Ø 4 x 12 mm</p>	<p>K x 2</p> 	<p>L x 4</p>  <p>Ø 4 x 12 mm</p>	<p>S x 4</p> 	
---	--	---	---	---



Fix hinge(S) to plate 19 with screw(G) as shown.



Fix handle(K) to door plate with screw(L) as shown.






24

G x 40




Ø4 x 12 mm



Attach door plate 18 to upper cabinet by fixing hinge with screw(G) as shown.

Attach door plate 28 and 29 to lower cabinet by fixing hinge with screw(G) as shown.







25


G x 16



Ø4 x 12 mm



Attach door plate 19 to upper cabinet by fixing hinge with screw (G) as shown.




26

H x 2





Ø4 x 12 mm

V x 2




Fix part(V) to plate 5 with screw(H) as shown.



27




Q x 2




R x 2






Ø6 x 30 mm



Install anti-tipping device as shown.



WALL



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.