

**POWER  
CURVE™**  
TECHNOLOGY

POWER CURVE TECHNOLOGY with its 6-blade fan design has 30% higher airflow for maximum cooling.

The TRIPLE-ZONE tri-curve grille eliminates turbulence for a stronger airflow with 20% less noise!\*

\*Note: Compared to a non-curved fan grille



# 18" Turbo Performance Stand Fan

**Features:**

- 2-In-1 Fan Design: Stand or Wall-Mountable
- Push-Button Control with 3 Speed Settings
- Tri-Curve Plastic Safety Grille
- 6 Fan Blades
- Adjustable Tilt Head
- Wide Area Oscillation
- Adjustable Stand up to 53in. Height
- 120V A.C. / 60Hz



## INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial applications. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. If you have any questions whether your wiring is adequate, consult a qualified electrician.

While using your fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word "**WARNING**" to indicate the level of hazard: **WARNING** indicates a hazard which, if not avoided, could result in injury or death

## IMPORTANT INSTRUCTIONS

As with all electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, fire, or injury to persons, including the following precautions:

- Read all the instructions before using this fan.
- Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause electrical shock, fire or injury to persons.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Use of extreme caution is necessary when any fan is used by or near children, disabled persons or pets and whenever the fan is left operating unattended.
- Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.
- For proper operation, fan should be placed on a smooth, non-combustible, level surface.
- Always unplug fan when not in use, when moving from place to place, when assembling or disassembling parts, and before cleaning.
- The use of attachments, not recommended or sold by the manufacturer, may cause hazards.
- Do not use outdoors.
- Do not use fan in window. Rain may cause electrical hazard (for non-window models).
- Do not operate the fan with blade guards or any safety device removed.
- Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less than 1875 watts.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.
- Do not insert or allow any object to enter any openings on the fan. Doing so may cause electric shock and/or fire hazard. Avoid contact with moving parts.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.

### **WARNING: SHOCK HAZARD**

Use your fan only in dry environments. This fan is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. DO NOT use in damp environments such as flooded basements.

### **WARNING: HOT SURFACES**

DO NOT touch fan motor when in use. This motor is hot when in use, to avoid burns, do not let bare skin touch hot surfaces.

### **WARNING: FIRE HAZARD**

Fans have arcing or sparking parts inside. DO NOT use near combustible materials or flammable gases or sources of heat. DO NOT use in areas where gasoline, paint or flammable materials are used or stored. To prevent a possible fire, do not block air intakes or exhaust in any manner. DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the fan.

### **WARNING: ELECTRICAL SHOCK HAZARD**

DO NOT use with damaged cord or plug. Use with adequate electrical system that is up to code. DO NOT use this product with any solid-state speed control device.

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defeat this safety feature.

### **WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,**


DO NOT operate any heater with a damaged cord or plug or after heater malfunctions, has been dropped or damaged in any manner. DO NOT operate heater with a broken heating element or ceramic cone or any visual imperfections. For repairs covered under warranty, see warranty statement. For all other repairs contact Comfort Zone® Customer Service by telephone or mail for information and assistance.

DO NOT run power cord under carpeting. DO NOT cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over. Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less than 1875 watts. DO NOT use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not in use. DO NOT operate fan with its ventilation obstructed.

## READ & SAVE THESE INSTRUCTIONS

## PARTS IDENTIFICATION

1. Front grille
2. Rear grille
3. Grilles' clips
4. ST 3x8mm Screw with washer top: (secures rear grille to motor cover)
5. M3x20 Screw and M3 Nut (secure grilles' interlock)
6. Fan blades
7. Blades nut
8. Motor shaft
9. Motor body
10. Oscillation switch
11. Operation/Speed control panel
12. Fan-to-pole fixing knob
13. Telescopic pole
14. Height fixing ring
15. Telescopic tube
16. Fan base
17. Counterweight
18. Washer
19. L- screw
20. Wall fan support bracket



## ASSEMBLY INSTRUCTIONS

### Fan Head Assembly:


#### Step 1:

Set the back grille on the motor shaft. Make sure that the internal molded arrow (Fig. 1a) points up and the 4 clips fit properly. Push firmly in order to fit them tightly (Fig. 1b). Make sure they are secure.

Fig. 1a




Fig. 1b



#### Step 2:

Using a Philips-head screwdriver, screw the **3x8mm screw with washer top** (included in the parts kit) into the cylinder-shaped housing at the top of the grille (Fig. 2).


Fig. 2



#### Step 3:

Set the fan blades on the shaft of motor body and screw the blades nut toward the word "TIGHTEN" as the arrows show (Fig. 3).

Fig. 3






#### Step 4:

Place the front and back grilles together by aligning the 12 clips, pushing firmly until a "click" sound is heard (Fig. 4a, 4b).

Fig. 4b

Fig. 4b

Clip



#### Step 5:

- Take the **M3mm nut** (from the parts kit) and place it on the hex socket at the bottom of the rear grille (Fig. 5a).





Fig. 5a



- Next, take the **M3x20mm screw** (from the parts kit) and place it on the socket at the bottom of the front grille (Fig. 5b).

Fig. 5b



- Secure the screw to the nut to ensure the firm grip of both grilles using a Philips-head screwdriver.



## STAND FAN ASSEMBLY:

### Base Assembly:

#### Step 1:

Unscrew the **L-screw** from the telescopic tube washer and set the tube inside the base's round hole (Fig. 1).

#### Step 2:

Place the counterweight at the bottom of the base. Set the washer under the counterweight so that the dome piece touches the counterweight (Fig. 2).

#### Step 3:

Screw the L-screw clockwise into the washer, holding the telescopic tube until it is tight into the base (Fig. 3).





Fig. 3



### Mounting the Fan on the Base:

#### Step 1:

- Loosen the height fixing ring (A) located on the telescopic tube by turning it counterclockwise and lift the telescopic pole until it reaches the desired height.


**NOTE:** The pedestal extension pole may be recessed inside the larger pole of pedestal body.




- Screw the ring (A) clockwise until it is tight enough to secure the telescopic pole height.

#### Step 2:

Unscrew the fixing knob (B) and fit the telescopic pole inside the motor body. Make sure to reach the bottom of the engine body base and screw the fixing knob clockwise until it is tight.



**Stand Fan Assembled**



## WALL MOUNTING

This fan comes with a wall mounting option.

**Note:** It is not recommended to install the fan support bracket on prefabricated walls or unstable walls. The fan should be level when mounted and at least one of the two mounting screw locations should be a wall stud.

#### Step 1:

- Using a 1/4-in drill bit, drill two horizontally aligned holes in the wall with 1.5-inch separation between them.

- Push a 1/4-inch plastic anchor (included) in each hole.

- Insert a 1/4-inch x 1-inch screw (included) in each anchor and screw it into the anchor body no more than 0.78 inches deep (Fig. 1).

#### Step 2:

Set the previously assembled motor body with the fan head onto the wall fan support bracket (Fig. 2) and tighten it from behind with the fixing knob (Fig. 2a).

#### Step 3:

Mount the bracket with fan on the previously set two wall screws (Fig. 3) and make sure it is set properly (Fig. 3a).




Fig. 1



Fig. 2



Fig. 2a





Fig. 3




Fig. 3a

### Wall-mounted Fan



## Oscillation Switch:

The oscillation control knob may not be attached when the fan is first removed from the box. To attach, locate the oscillation control knob inside the plastic bag that contains the parts of the fan. Insert the oscillation control knob inside the engine body hole assigned for it and push down firmly until a “click” sound is heard. Make sure the oscillation control knob is correctly assembled.



## USAGE

**Fan Operation:** Always operate the fan on a stable surface. Do not set on a rug, over furniture, on an uneven floor or on a fabric surface. Always follow all instructions and recommendations listed in this manual.

**Fan Location:** Place the fan in the area of the room that will provide proper fan cooling. Do not set your fan closer than 4 inches from any surface such as the wall, curtains or any furniture which could block the air flow.


**Fan Connection:** Make sure the fan is in the OFF position on the control panel before plugging in. Plug the fan directly into 120 volt A.C., 60Hz wall outlet. Be sure plug fits tightly into the outlet. A loose connection may cause overheating and damage to the plug or fan.

**Note:** To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

**Turning Fan On/Off:** To start the fan, push the speed button to the desired fan speed: LOW, MEDIUM or HIGH (0-OFF, 1-Low, 2-Medium, 3-High). Push the OFF button to discontinue use. Unplug fan when not in use.

**Oscillation:** To start fan oscillation, pull the Oscillation Control Knob up (located above motor housing). To stop oscillation function press Oscillation Control Knob down.

The fan’s head angle can be horizontally adjusted by pulling the Oscillation Control Knob up so that it will move on 150 degree oscillation range. You can set it to the desired position by pushing the Oscillation Control Knob down in.



## CARE AND MAINTENANCE

**Cleaning:** CAUTION-Before cleaning the fan be sure to unplug the power cord from the outlet. Clean the grille surface with a clean damp cloth. Clean the fan blades with a soft, lightly wet soapy cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Replace front grille before fan use. Allow fan to dry completely before use. Periodic grille cleaning with a vacuum will prevent dust build up. The motor is sealed and does not require any interior maintenance, cleaning or lubrication.

**Maintenance:** The internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

**Repair:** DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

**Storage:** Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

## SAFETY FUSE

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

### Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades. See Fig. 2.
3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.
4. Replace fuse. WARNING: Risk of fire. Replace fuse only with identical 2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Make sure the fuse is properly seated within its cavity.
5. Close fuse cover by sliding it back to its original closed position.

Fig. 1



Fig. 2



Fig. 3



## LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, freight prepaid, to World and Main for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than World and Main are not covered in this warranty. World and Main will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Manufactured for:  
World and Main (Cranbury), LLC  
324A Half Acre Rd.  
Cranbury, NJ 08512 USA  
800-221-6895

[www.comfortzoneproducts.com](http://www.comfortzoneproducts.com)

Rev. 01/10/2022