Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

Water Damage

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage and is considered negligence and will, therefore not be covered under this warranty. The use of "hard water" and/or caustic cleaners can affect the paint or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation

• Paint & Color (Retention and/or Loss)

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading within the first year from date of purchase with the above exclusion.

Procedure/Service

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that is not an option, you can contact Alpine Corporation at <u>www.alpine4u.com</u>. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. Item is covered under *two year limited warranty* from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges

Not Covered Under Warranty

The limited warranty will NOT cover cases of damages due to

- 1. Damages caused in Transit
- 2. Inadequate care and/or neglect
- 3. Environmental and/or natural elements
- 4. Immersion in water, unless specified

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.





WIN270S Rainforest Waterfall Tree Trunk Fountain with LED Lights




This product is protected by U.S. Patent # D643,504 S


Assembling & Using Your Product

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging. Some splashing may occur when the product is in use.

Components:

- A) Fountain
- B) Submersible Pump
- C) Transformer
- D) Back Cover





Assembling Instructions:

- 1. Place the Fountain (A) on a smooth and level surface.
- 2. Remove the Submersible Pump (B) from its packaging and adjust the flow control to the lowest setting to avoid splashing until the Fountain (A) is completely assembled.
- **3.** Then, connect the vinyl tubing from the opening in the back of the Fountain (A) and connect to the Submersible Pump (B) (see step 1 above). After, place the Pump (B) into the bottom of the reservoir through the opening in the back of the Fountain. Feed the Pump power cord out through the cut-out slot at the back of the Fountain.
- 4. Pull out the LED light cord from the opening in the back of the Fountain (A). Then, connect the LED light cord to the Transformer (C) by inserting the male prong socket into the female plug of the Transformer (see step 2 above). Feed the cord out through the cut-out slot at the back of the Fountain.
- Gently pour water into the Fountain (A), being careful not to overflow and cause splashing. Make sure the water completely submerges the Submersible Pump (B) so the water runs clear during operation (see step 3 above).
- 6. Place the Back Cover (D) over the opening behind the Fountain (A) by sliding it back in. Make sure the LED and Submersible Pump (B) power cord are fed through the cut-out slot to avoid getting caught by the cover (See step 4 above).
- 7. Plug the cords for the LED light and Submersible Pump (B) into your local power supply. Make sure that there is no water around the plugs and always keep the power source in a dry place (see step 5 above).
 - **NOTE:** We recommend using distilled water to prevent scale build-up. The first time you operate the pump it can take up to 5 minutes for the air to be completely expelled and water begins to flow properly.

Trouble Shooting & Caution

If you have any questions and/or problems, please contact the retail store you purchased this fountain.

- If your pump fails to run
 - Check the circuit breaker or try a different outlet to make sure the pump is receiving electrical power.
 - Check the pump discharge and tubing for any kinks and/or obstructions.
 - Any buildup obstructing the water flow can be flushed with a garden hose.
 - Check the rotor by removing the front cover & plate to access the impellor area. Turn the rotor and make sure that the rotor is not jammed or broken.
- If your pump "spews"
 - Check the water level to make sure the pump is completely submerged and there if enough water in the basin to operate your fountain. Not having enough water will cause your pump to spew.
- If your pump is making abnormal loud noises
 - Disconnect the pump from the electrical power supply and remove the front cover and plate.
 - Carefully grip the impeller and gently pull the impeller/rotor assembly out of the pump housing.
 - Rinse the impeller/rotor assembly and clean the cavity with clean water. If breakage or damage is found, contact your local retailer for parts.
- Fountain Care
 - We recommend using Alpine Item PPL102's all-natural cleansing formula to eliminate foam, lime scale, and calcium buildup; fight mineral deposits; leave water crystal clear; help prevent staining; remove organic contaminants; and treat discolored water. This formula will help prevent pump damage due to hard water build up. For more information, please visit <u>www.alpine4u.com</u>.



- Caution
 - Always unplug the pump from the electrical outlet before cleaning and handling.
 - Use with clean water only, do not place the fountain and/or parts in any other liquid.
 - Periodically change water & clean the pump to keep free from micro-organisms.
 - Disconnect and store the unit in a dry place if not in use for an extended period of time.
 - \circ $\,$ Do not lift, carry, or pull the pump by the power cord.
 - Do not exceed the maximum voltage & wattage on transformer.
 - \circ ~ NEVER LET THE PUMP RUN DRY.