




















Part List

1	LEFT TOP BAR		1
2	RIGHT TOP BAR		1
3	CROSS BAR		2
4	TOP SECTION LEG		4
5	BOTTOM SECTION LEG		4
6	TREE SWING		1
7	CHAIN SWING CHAIR		1
8	ROPE		2
9	ANCHOR		4
A	Bolt, Washer M8*63		14
B	Bolt, Washer M8*63		4
C	Plastic Cap		24
D	U-BOLT SET		2
E	9-shaped hook		2
F	HANGER		4
G	HEX KEY		2


SAFETY

1. Before assembling the Fitness Playground, find level ground no less than 6 feet from any structure or obstruction to the Fitness Playground. The Fitness Playground must have clearance on all sides.
2. To prevent serious injury, do not allow children to play on the Fitness Playground until it is completely installed.
3. Do not install the Fitness Playground over concrete, packed dirt, or any other hard surface. A fall onto a hard surface can result in serious injury.
4. Only adults should assemble or disassemble this Fitness Playground.
5. This product **MUST** be anchored.
6. Adult supervision of children is required at all times when on or around this Fitness Playground. Never leave children unattended.
7. Do not swing too high or at an angle.
8. Do not hang on or climb from structural members of the Fitness Playground.
9. Do not exceed the intended weight limit or maximum number of users for the Fitness Playground.
10. This product is suitable for children over 5 years old or adults, and can accommodate 3-4 children at the same time.
11. Be sure to observe your children and ensure that they have the strength and skills to enjoy all the rides safely before use on their own.
12. Do not allow children to walk close to, behind, or in front of moving items.
13. Do not allow children to twist the chains on the swing or loop them over the top bar. This may reduce the strength of the chain.
14. Teach and instruct children not to swing empty seats.
15. Instruct children how to sit in the center of the seats and swing with their full weight on the seat.
16. Warn children not to use the equipment in any manner other than intended.
17. Warn children not to get off the rides while in motion.
18. Equipment may be slippery when wet. Do not allow children to use the equipment when wet.
19. Parents should regularly check openings and surfaces, for items that may be hazardous.
20. Parents should check swing chains to ensure they are secure.
21. Do not place any part of the body near moving parts.
22. Never slide head first down the slide.
23. Ensure that all swings and chains are secured at both ends.
24. Never attach any materials that are not specifically designed for use with this swing set . such as jump ropes, pet leashes, rope or cords and other chains as these pose a potential strangulation hazard.
25. Children must be supervised at all times. No playground is safe without adult supervision.
26. Improper usage or installation of Basketball hoop can cause serious inj.








STEP1




STEP2



STEP3



STEP4



STEP 5