



fox&summit™

Standard Bundle

FS-BNDL1

Quick Start Guide

What's in the Wi-Fi LED Light Bulb Box



Wi-Fi LED Light Bulb



Quick Start Guide

Wi-Fi LED Light Bulb Safety Instructions


- Be sure your light fixture or lamp is switched OFF before installing the Wi-Fi LED Light Bulb.
- Your existing light bulb may be HOT, so allow the bulb to cool down before removing.
- Do not put your fingers in the exposed light bulb socket.
- Practice safe installation habits while installing your Wi-Fi LED Light Bulb.
- Properly dispose of your old light bulb and keep it out of reach of children.

Wi-Fi Operation Warnings

- Always check that your smartphone or tablet OS and FS Home App is running the most up-to-date version.
- Check that your Wi-Fi router is working properly and operates on 802.11b/g/n 2.4GHz with WPA/WPA2 encryption. The App does not support any other network encryptions.
- DO NOT use a 5GHz Wi-Fi network.

Wi-Fi LED Light Bulb Installation and App Setup

1. **Download** the FS Home App  from the App Store or Google Play.



App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

2. **Connect** your smartphone or tablet to your local 2.4GHz Wi-Fi network.



3. Turn off the power to your light fixture and/or unplug it from its power source before removing the existing light bulb. Your existing light bulb may be HOT, so allow the bulb to cool down before removing.
4. Screw in the Wi-Fi LED Light Bulb into the light fixture or socket. Do **NOT** turn on the power to the fixture or socket just yet.
5. **Launch** the FS Home App.
6. **Sign up** for an account or **Login** with your email or password.
7. Go to  "Device" and press "+" in the upper right-hand of the screen and follow the on-screen pairing instructions.

To Pair New Device

Make sure your phone is connected
to a 2.4GHz Wi-Fi network

Start

Wi-Fi NAME


.....



Important: Ensure that the network name or SSID is the desired network you want the devices to use. If it is different from your smartphone's Wi-Fi settings, your device pairing will be unsuccessful.

8. Enter your Wi-Fi network password.


9. **Scan** the device QR-Code/UID with your smartphone or tablet or enter it manually. The QR-Code is located on the Light Bulb itself, as pictured below.



10. **Plug in** or **power up** your light fixture with the Wi-Fi LED Light Bulb.
11. Press "**Pair**" in the FS Home App within 10 seconds of turning on power to the light socket.

Important: When pairing is successful, a new device will be added to your Device page. If unsuccessful, repeat Step 7.

What's in the Wi-Fi Indoor Plug Box



Wi-Fi Indoor Plug



Quick Start Guide

Wi-Fi Indoor Plug Safety Instructions

- Be sure there are no exposed wires from the wall outlet or Wi-Fi Indoor Plug before installation.
- Your Wi-Fi Indoor Plug is intended for indoor use only.
- Do not tamper with or make any modifications to your Wi-Fi Indoor Plug.
- Do not insert your Wi-Fi Indoor Plug into a wall outlet if the device or wall outlet is wet or there is moisture around the desired area of installation.
- Plug directly and completely flush into the wall outlet.
- Do not plug other electronic devices into your Wi-Fi Indoor Plug that exceed the maximum electrical load rating.
- Best used when plugged into wall outlets that are not controlled by a manual switch.

Wi-Fi Operation Warnings

- Always check that your smartphone or tablet OS and FS Home App is running the most up-to-date version.
- Check that your Wi-Fi router is working properly and operates on 802.11b/g/n 2.4GHz with WPA/WPA2 encryption. The App does not support any other network encryptions.
- DO NOT use a 5GHz Wi-Fi network.

Wi-Fi Indoor Plug Installation and App Setup

1. Insert your Wi-Fi Indoor Plug into the desired wall outlet location.

Wi-Fi Indoor Plug Power Rating:

Input: AC 100-120V, 50-60Hz

AC Outlet: AC 100-120V, 50-60Hz, Maximum Output 10A

Consumption: Typ. < 1W

2. **Download** the FS Home App  from the App Store or Google Play.


🔍 FS Home



App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

3. **Connect** your smartphone or tablet to your local 2.4GHz Wi-Fi network.



4. **Launch** the FS Home App.

5. **Sign** up for an account or Login with your email or password.

6. Go to  **"Device"** and press **"+"** in the upper right-hand of the screen and follow the on-screen pairing instructions.

To Pair New Device

Make sure your phone is connected
to a 2.4GHz Wi-Fi network

Start


Wi-Fi NAME

.....




Important: Ensure that the network name or SSID is the desired network you want the devices to use. If it is different from your smartphone's Wi-Fi settings, your device pairing will be unsuccessful.

7. Enter your Wi-Fi network password.
8. **Scan** the device QR-Code/UID with your smartphone or tablet or enter it manually. QR-Code is located on the bottom of the Wi-Fi Indoor Plug



9. Insert Indoor Plug into an available power outlet. Once it has beeped, press and hold the button on the front of the plug until it emits one long beep, then release the button.



10. Press "**Pair**" in the FS Home App within 10 seconds of releasing the button on the front of the Indoor Plug.

Important: When pairing is successful, a new device will be added to your Device page. If unsuccessful, repeat Step 6.

What's in the Wi-Fi Window/Door Sensor Box



Wi-Fi Window/Door Sensor



Quick Start Guide



Screwdriver



2 AAA Batteries

Wi-Fi Window/Door Sensor Safety Instructions


- Practice safe installation habits while installing the Wi-Fi Window/Door Sensor.
- Your Wi-Fi Window/Door Sensor is intended for indoor use only.
- Do not tamper with or make any modifications to your Wi-Fi Window/Door Sensor.
- Make sure you replace batteries with 2 new AAA alkaline batteries. Insert batteries in the correct polarity as shown inside the battery case.
- Properly dispose of old batteries in accordance with local regulations. Do not discard with any other household waste.
- Keep batteries away from small children and pets.
- Use only a dry cloth when cleaning your Wi-Fi Window/Door Sensor.
- Do not install your Wi-Fi Window/Door Sensor near any heat source or any home equipment that produces heat.

Wi-Fi Operation Warnings

- Always check that your smartphone or tablet OS and FS Home App is running the most up-to-date version.
- Check that your Wi-Fi router is working properly and operates on 802.11b/g/n 2.4GHz with WPA/WPA2 encryption. The App does not support any other network encryptions.
- DO NOT use a 5GHz Wi-Fi network.

Wi-Fi Window/Door Sensor Installation and App Setup

1. **Download** the FS Home App  from the App Store or Google Play.



App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

2. **Connect** your smartphone or tablet to your local 2.4GHz Wi-Fi network.



Your Smartphone



Your Wi-Fi Router

3. **Launch** the FS Home App.
4. **Sign up** for an account or **Login** with your email or password.
5. Go to  **"Device"** and press **"+"** in the upper right-hand of the screen and follow the on-screen pairing instructions.

To Pair New Device

Make sure your phone is connected
to a 2.4GHz Wi-Fi network

Start

Wi-Fi NAME


.....




Important: Ensure that the network name or SSID is the desired network you want the devices to use. If it is different from your smartphone's Wi-Fi settings, your device pairing will be unsuccessful.

6. Enter your Wi-Fi network password.

7. Using the provided screwdriver to remove the battery cover.
Do **NOT** unscrew the four screws on the back of the sensor.



8. **Scan** the device QR-Code/UID with your smartphone or tablet or enter it manually. The QR-Code is located on the inside of the battery cover.




9. Insert 2 new AAA batteries. Make sure you insert batteries in the correct polarity.




10. Press "**Pair**" in the FS Home App within 10 seconds of inserting the batteries.

Important: When pairing is successful, a new device will be added to your Device page. If unsuccessful, repeat Step 5.


11. Install the Wi-Fi Window/Door Sensor onto the desired window or door with the included adhesive strips.



Recessed Door




Sliding Window



Cupboard

*Sensor and magnet must be less than 1/2" (12mm) apart.



* If mounting on a metal door or gate, make sure you elevate the sensor and magnet by 1/4" to 1/2" to prevent it from magnetizing the metal.

What's in the Wi-Fi Control Button Box



Wi-Fi Control Button



Quick Start Guide



2 X AAA Batteries

Wi-Fi Control Button Safety Instructions


- Practice safe installation habits while installing the Wi-Fi Control Button.
- Your Wi-Fi Control Button is intended for indoor use only.
- Do not tamper with or make any modifications to your Wi-Fi Control Button.
- Make sure you replace batteries with 2 new AAA alkaline batteries.
Insert batteries in the correct polarity as shown inside the battery case.
- Properly dispose of old batteries in accordance with local regulations.
Do not discard with any other household waste.
- Keep batteries away from small children and pets.
- Use only a dry cloth when cleaning your Wi-Fi Control Button.
- Do not install your Wi-Fi Control Button near any heat source or any home equipment that produces heat.

Wi-Fi Operation Warnings

- Always check that your smartphone or tablet OS and FS Home App is running the most up-to-date version.
- Check that your Wi-Fi router is working properly and operates on 802.11b/g/n 2.4GHz with WPA/WPA2 encryption. The App does not support any other network encryptions.
- DO NOT use a 5GHz Wi-Fi network.

Wi-Fi Control Button Installation and App Setup

1. **Download** the FS Home App  from the App Store or Google Play.



App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

2. **Connect** your smartphone or tablet to your local 2.4GHz Wi-Fi network.



Your Smartphone



Your Wi-Fi Router

3. **Launch** the FS Home App.
4. **Sign up** for an account or **Login** with your email or password.
5. Go to  "Device" and press "+" in the upper right-hand of the screen and follow the on-screen pairing instructions.

To Pair New Device

Make sure your phone is connected
to a 2.4GHz Wi-Fi network

Start

Wi-Fi NAME


.....




Important: Ensure that the network name or SSID is the desired network you want the devices to use. If it is different from your smartphone's Wi-Fi settings, your device pairing will be unsuccessful.

6. Enter your Wi-Fi network password.

7. Open the front cover of the Control Button by holding the back cover firmly and pulling open the front from the top. Do **NOT** unscrew the four screws on the back.



8. **Scan** the device QR-Code/UID with your smartphone or tablet or enter it manually. The QR-Code is located just under the battery cover. See the pictures below:



9. Insert the batteries into the Control Button.



10. Press "**Pair**" in the FS Home App within 10 seconds of inserting the batteries.

Important: When pairing is successful, a new device will be added to your Device page. If unsuccessful, repeat Step 5.

11. While still in the FS Home App, go to the Wi-Fi Control Button settings and program the button to activate or control specific actions or scenes for your Fox & Summit Wi-Fi buttons, lights, and/or plugs.

Note: When setup is complete, test your device by pressing the control button to activate or deactivate programmed actions. Remember that each Control Button can control two different things by pushing it once or twice.

Troubleshooting

1. Pairing Unsuccessful

- a. Make sure that your smartphone or tablet is connected to the desired Wi-Fi network.
- b. Make sure that the Wi-Fi network your smartphone or tablet is connected to is a 2.4GHz network, not a 5GHz network. This is only necessary when pairing.
- c. Make sure that the Wi-Fi signal is strong at the desired installation location.
- d. Unplug or power down other Wi-Fi devices to minimize wireless interference during setup.
- e. Double check that you are entering the correct Wi-Fi network password.

2. Doesn't work properly | Signal Loss

- a. Check that your Fox & Summit device location is within Wi-Fi range.
- b. Depending on your device's location, using a Wi-Fi range extender may be necessary.
- c. Check that your Wi-Fi router is working properly. Consult the manufacturer of your Wi-Fi router for more information.

For more product help and support visit:

www.foxandsummit.com/apps/help-center

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



CE marking on this product represents the product is in compliance with all directives that are applicable to it.



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

Battery Safety Information

Caution: Keep batteries away from small children. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries promptly in accordance with local regulations.



WARNING: Cancer and Reproductive Harm -
www.P65Warnings.ca.gov.

