




INSTRUCTION MANUAL



Wicker Sofa Set



CUSTOMER SERVICE

Thanks for ordering PATIO TIME furniture. When you have any question regarding of assembly or accessories, please do not hesitate to contact our customer service.

Address: 6366 Corley Road, Norcross, GA 30071.

Telephone: (800) 366-8649

Website: www.patiotimeusa.com

E-mail: info@patiotimeusa.com

Service time: Monday-Friday, 8:30AM-5:30PM, EST

CARE AND MAINTENANCE

Following the instructions to make the item remain in its best status as long as possible. The solutions below are only regarded as a general guideline. For more information, please contact us.

Rinse it thoroughly with clean water to wash away dirt and grime. Never use abrasive cleanser on the furniture, since it can damage the surfaces and leave scratch marks.

For the stubborn grime and stains, use a soft sponge and mild soapy water, and then dry it with a cloth or paper towel.

Check the stability of screws, nuts and nut caps in priority. Tighten up them after one(1) to two(2) months' use whenever required.

Avoid improper use and be careful not to scratch or damage the surface with sharp objects.

When moving furniture, make sure lifting it rather than pulling or pushing it so as to avoid any damage to the floor, legs and mounting.

INTRODUCTION


Patio Time is appreciating your trust and purchase for supporting your home decorating plans. This item is designed ergonomically and manufactured by Patio Time.

Patio Time is always devoted to R&D innovation and each year launches diverse outdoor collections with high quality.

After unpacking, please check if the parts show any damage. In addition, please check if all parts and hardware are in position before assembly. If there is any damage or missing, please do not assemble firstly and call customer service at (800) 257-7108 directly or send an email to info@patiotimeusa.com. If you do not have the parts lists, you can require your dealer to send you immediately.

This furniture can be applied for both indoor and outdoor environment. Please take time to read and follow the instructions below. Use the item as described in this operating manual. Patio Time will not be liable for any damage caused by improper use.

May you enjoy your patio time!



Step1: Attach chair's frame (A) to 2 front legs (B), 2 back legs(C) using 3 bolts (F), 3 spring washers(G), 3 flat washers (E).


Step2: Attach chair's frame (A) to 2 middle legs (D) using 2 bolts (F), 2 spring washers (G), 2 flat washers(E).







Step 3:Upon completion of full assembly and bolted up-all screws can be tightened down.

Note:Please do not tighten any bolt until all bolts have been put into right place.



If you tighten one bolt, it maybe cause other bolts out of position.

1






Part Number	Images and Sizes	Qty.
A		1
B		2
C		2
D	 M6*ø16	12
E	 M6*20	12
F	 M6*ø9.5	12





Part Number	Images and Sizes	Qty.
A		1
B		2
C		2
D	 M6*ø16	2
E	 M6*ø16	16
F	 M6*20	16
G	 M6*ø9.5	16

1



2



Step 1: Attach chair's frame (A) to 2 front legs(B) and 2 back legs(C) using 3 bolts (E), 3 spring washers (F) and 3 flat washers (D).


Step 2: Upon completion of full assembly and bolted up- all screws can be tightened down.

Note: Please do not tighten any bolt until all bolts have been put into right place.

If you tighten one bolt, it maybe cause other bolts out of position.



INSTRUCTION MANUAL



Wicker Coffee Table



INTRODUCTION

Patio Time is appreciating your trust and purchase for supporting your home decorating plans. This item is designed ergonomically and manufactured by Patio Time.

Patio Time is always devoted to R&D innovation and each year launches diverse outdoor collections with high quality.

After unpacking, please check if the parts show any damage. In addition, please check if all parts and hardware are in position before assembly. If there is any damage or missing, please do not assemble firstly and call customer service at (800) 257-7108 directly or send an email to info@patiotimeusa.com. If you do not have the parts lists, you can require your dealer to send you immediately.

This furniture can be applied for both indoor and outdoor environment. Please take time to read and follow the instructions below. Use the item as described in this operating manual. Patio Time will not be liable for any damage caused by improper use.

May you enjoy your patio time!

CARE AND MAINTENANCE

Following the instructions to make the item remain in its best status as long as possible. The solutions below are only regarded as a general guideline. For more information, please contact us.

Rinse it thoroughly with clean water to wash away dirt and grime. Never use abrasive cleanser on the furniture, since it can damage the surfaces and leave scratch marks.

For the stubborn grime and stains, use a soft sponge and mild soapy water, and then dry it with a cloth or paper towel.

Check the stability of screws, nuts and nut caps in priority. Tighten up them after one(1) to two(2) months' use whenever required.

Avoid improper use and be careful not to scratch or damage the surface with sharp objects.

When moving furniture, make sure lifting it rather than pulling or pushing it so as to avoid any damage to the floor, legs and mounting.

CUSTOMER SERVICE

Thanks for ordering PATIO TIME furniture. When you have any question regarding of assembly or accessories, please do not hesitate to contact our customer service.

Address: 6366 Corley Road, Norcross, GA 30071.



Telephone: (800) 366-8649

Website: www.patiotimeusa.com

E-mail: info@patiotimeusa.com

Service time: Monday-Friday, 8:30AM-5:30PM, EST

2




Step1: Attach table top (A) to leg(C/D) using 3 bolts(F), 3 spring washers(H), 3 flat washers(E) respectively. Do not over tighten.









Step2: Attach support frame(B) and leg(C/D) using 1 bolt(G), 1 spring washer(H) and 1 flat washer(E) respectively . Do not over tighten.

Step3: Upon completion of full assembly, all screws can be tightened down.

Note: Please do not tighten any bolt until all bolts have been put into right place.

If you tighten one bolt, it may cause other bolts out of position.



Part Number	Images and Sizes	Name	Qty.
A		Table top	1
B		Supporting frame	1
C		Legs	2
D		Legs	2
E	 M6* \varnothing 16	M6 flat washer	16
F	 M6*20	M6 hexagon socket head cap screw(20)	12
G	 M6*30	M6 hexagon socket head cap screw (30)	4
H	 M6* \varnothing 9.5	M6 spring washer	16

