

SAFAVIEH OUTDOOR

CARE AND USE GUIDE

Product Dimensions: 18"W X 18"D X 40"H



Table of Contents

| | |
|-------------------------|---|
| Table of Contents..... | 2 |
| Safety Information..... | 2 |
| Precautions | 2 |
| Pre-Assembly | 3 |
| Package Contents | 3 |

| | |
|-------------------------|---|
| Assembly | 4 |
| Operation | 5 |
| Care and Cleaning | 5 |

Safety Information

PRECAUTIONS

Use caution and common sense when using your outdoor fireplace. Failure to adhere to the safety warnings and guidelines in this manual could result in bodily injury or property damage. Save this manual for future reference.



WARNING: Fuels used in wood or charcoal burning appliances combustion of such fuels, contain chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.



DANGER: To prevent personal injury, burns, property damage, or even death, carefully monitor all activity and alert all persons in the vicinity of burning outdoor fireplaces of the dangers and safety precautions associated with open flame fireplaces. Do not use outdoor fireplaces where alcoholic beverages are being consumed.



DANGER: Keep children, pets, loose clothing, and hair safely away from the outdoor fireplace. Failure to adhere to this could lead to severe personal injury or possible death. Do not allow children to use or play near this outdoor fireplace.



DANGER: Do not use indoors due to the hazard of carbon monoxide fumes and fire. Lack of ventilation may cause death.



WARNING: For outdoor use only.



WARNING: Outdoor fireplaces are only to be used in a well ventilated area a minimum of 20 ft. from building walls, overhangs, trees, and so forth to prevent fires or melting of materials from buildings.



WARNING: Do not place the outdoor fireplace where flames could ignite combustible materials such as roof overhangs, wooden structures, fuel, clothing, fabric, or dry vegetation.



WARNING: To avoid fire hazards, never leave a burning outdoor fireplace unattended. If you must leave the area of the fire pit, ensure that all fire embers are extinguished.



WARNING: Place the outdoor fireplace out of the way of pedestrian traffic, trees, and tree branches.



WARNING: Use with extreme care and at your own risk.



WARNING: The metal surface can get very hot and caution must be used when handling the fireplace after use. Never move the outdoor fireplace when in use or immediately after use when it may be hot.



WARNING: Do not touch the flame or outdoor fireplace when in use.



WARNING: Do not use during windy conditions.



WARNING: Please check with your local fire municipality or authority on any restrictions of use.



WARNING: Do not overload the bowl beyond 6 to 8 pounds.



WARNING: Place the outdoor fireplace on firm, level ground or surfaces free of debris. Do not use on wooden or composite decks.



WARNING: It is advised that a fire extinguisher be readily available. Refer to your local authority to determine the proper size of the fire extinguisher.



WARNING: Do not use the outdoor fireplace for other than its intended purpose.



WARNING: Do not attempt to service or modify the fireplace other than normal maintenance procedures as explained in the Care and Cleaning section of this manual.




WARNING: Metal surfaces will become extremely hot during use. Always use caution when handling a spark screen and a screen lifting tool, if equipped. Failure to wear flame retardant, protective gloves while handling steel parts may lead to serious burns and injury.



WARNING: Never use gasoline, kerosene, alcohol, or other flammable fuel in or around the outdoor fireplace. Do not use the outdoor fireplace near gasoline or other flammable liquids, gases, or where flammable vapors may be present.

Pre-Assembly (continued)

PACKAGE CONTENTS




| Part | Description | Quantity |
|------|-------------------------|----------|
| A | Spark arrester cap | 1 |
| B | Chimney | 1 |
| C | Fire screen with handle | 1 |
| D | Grate | 1 |
| E | Bowl | 1 |
| F | Stand | 1 |
| G | Poker | 1 |

Assembly


1 Assembling the bowl, log grate and fire screen

- Place the stand (F) to the upright position on a flat surface and place the bowl (E) into the stand (F).
- Place the grate (D) into the bowl (E).
- Position the fire screen (C) onto the bowl (E) so that it is resting on the inside ledge of the bowl. Make sure all components are square and level.



2 Assembling the chimney and spark arrester cap

- Carefully attach the spark arrester cap (A) to the chimney (B) by pushing down into the top of chimney (B).
- Carefully place chimney (B) onto the fire screen (C).



Operation

1 Starting a fire



WARNING: Do not use charcoal or an artificial log.



WARNING: Do not use large logs. Do not overload the fire bowl beyond 6 to 8 pounds.



WARNING: Do not use gasoline or kerosene to start a fire.




CAUTION: Keep the fire at a reasonable level as large fires can damage or shorten the life of the unit.

- Place three to four sheets of crumpled newspaper on top of the fire log grate (D).
- Pile finely-split, dry firewood on top of the loosely crumpled newspaper.
- When the location setting is established, light the loosely crumpled newspaper underneath the firewood and close the door of the mesh fire screen by using fire/heat resistant gloves or the Poker (G).
- Be sure the spark arrester cap provided is in place at all times and the hinged access door on the fire screen is closed during use.

2 Adding wood to an existing fire

- Use the poker (G) to lift the handle and open the door of the fire screen (C) and carefully add wood while the fire is burning.
- After adding the wood, use the poker (G) to close the door of the fire screen (C).



Care and Cleaning

- Once the fireplace is completely cooled down, remove the chimney and fire screen. Pour the ashes from the bowl and rinse with clean water and allow to dry completely.
- Clean after each use.
- Do not use a scrub brush.
- If the paint chips, use only high-temperature paints and a brush to fix.
- If rust is showing, sand lightly and repaint the area with high-temperature paints.
- Dry with a soft cloth.
- Turn the unit upside down when not in use to prevent water from collecting.
- Cover the unit when not in use to prolong the life.
- Keep your firepit out of rain.