

Product Detail

- Material: Steel pipe
- Load bearing: 330lb/150kg
- Platform swing cloth material: Teslin
- Chain material: Iron dipped in plastic
- Swing load: 330Lb/150KG

IMPORTANT SAFETY INSTRUCTIONS





This swing set is intended for use by children age from 3 to 12 years old. Not suitable for children under 3 years old.



On site adult supervision must be provided for children of all ages and at all times.

INSTALLATION NOTES

- DO NOT install swing set on concrete, asphalt or any other hard surface!
- · Recommended for installation on unpaved stable surfaces such as grass or hard sand.
- . The swing should be installed away from water sources and traffic roads to avoid accidents!
- The perimeter of the swing installation needs to be free of overhanging tree branches, clotheslines, wires and other obstructions to ensure safe play.
- · After the swing bracket is installed, a tension check should be carried out to ensure that the swing bracket is firm!
- The useless rope of the swing should be trimmed in time to avoid entanglement!
- · Swing chains and brackets should be regularly checked for stability and maintained regularly!


SAFETY INSTRUCTIONS

- · Teach your kids to play safely!
- · Children must use the swings under adult supervision!
- The load-bearing capacity of the swing is limited, do not exceed the specified number of people and weight. Otherwise, the swing
 may break or collapse.
- DO NOT play in wet weather conditions as the surface may be slippery.
- DO NOT attach extra items to the swing that are not specifically designed for the swing, including (but not limited to) clotheslines, electrical equipment, loose rope or chains, etc.
- DO NOT twist the swing chain or rope or wrap it around the top support bar, as this may reduce the strength of the chain or rope.
- Dress your child appropriately. Avoid placing accessories, garments with drawstrings, loose clothing, and items with cords around clothing, risk of injury!
- · When playing on the swing, you should sit firmly, hold the rope of the swing with both hands and don't stand up at will.
- Make sure that the climbing rope or chain is secured at both ends and cannot wrap around itself.
- · All components may become hot when exposed to direct sunlight. Make sure the swing is not hot before letting your child play.


WARN CHILDREN NOT TO


- Jump off while in motion on a swing set
- Swing an empty seat
- · Standing on a swing or kneeling on a swing
- Hang upside down on any part of exercise equipment
- Open hands or hold with one hand while swinging
- · Walk near, in front of, between, or behind a moving swing

Product Size




ASSEMBLY







Toolkit




INSTALLATION




Step 2



Step 3





Step 5

