Bathroom Cabinet Instruction Manual SG4718



TEL:(855)208-0668(MON-FRI 9:00am-6:00pm Eastern Time) Email:help@EverythingSupport.com



Hardware Usage Guide

HOW TO USE A CAM LOCK & CAM BOLT OR CAM DOWEL? **1.** NOTE: CAM BOLT or a CAM LOCK may be used.

2.



3. Insert the CAM BOLT into the CAM LOCK. Tighten the CAM LOCK.



4. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.



In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



Hardware List

- Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.
- Carefully and strictly follow these assembly&installation instructions to ensure a completed product as designed.
- Do not tighten all the screws until each part is properly assembled.

Item No.	Reference Image	Qty.	ltem No.	Reference Image	Qty.
A	Cam lock Ø15x11mm	x66		Screw Ø4x35mm	x10
B	Cam bolt Ø7x32mm	66	Ĵ	See 15	4 set
C	Wood dowel Ø8x40mm	x14	K	Bracket	x12
D	Shelf support	x8	Ĺ	Hinge	x4
E	Bolt Ø8mm	x4	Ø	Plastic anchor (8*30mm) with screw (4*50mm)	2 set
F	Allen key (M5)	x1		Glue	x1
G	Screw Ø4x14mm	x16	0	Sticker	x66
Ĥ	Screw Ø4x16mm	x72			



A x 8



Step 2



















Step 8

	A x 6
wer:	B x 6
0	C x 6











Step 10





A x 12



Step 12

A x 8

Image: Constraint of the second sec







Step 14

B	A x 4
(CEL)	B x 4













Step 20 OPTIONAL DOOR ADJUSTMENT

The cabinet doors have a three-way adjustment feature. Height, side-to side, level and depth can be adjusted. With the hinge slightly closed you can access the middle screw for up/down adjustment. With the hinge fully extended you can access the front and back screws. These screws will move the door side to side and in & out.



After adjusting, put the cover over the hinge as shown.





Remove the the protective layer of sticker, then use it to cover all cam-lock holes & bolt holes that you can see.







DETAIL HOLE FOR WALL FIXING Note: hammer is not included.



AFTER-SALES SERVICE CARD

We sincerely thank you for trusting our service and our products, and may this product add enrichment to your home. We guarantee that the product has undergone strict quality inspection and meticulous packaging. If you encounter any issue regarding either shipping or the product, please feel free to contact us at any time. We'd be more than happy to serve you wholeheartedly. Yours Sincerely.

• Please avoid harsh, corrosive and abrasive cleaners.

Customer Service:(855)208.0668(MON-FR1 9:00am-6:00pm Eastern Time)or contact help@EverythingSupport.com Address: 3005 Breckinridge Blvd, Suite 200, Duluth, GA 30096

If you have any questions or concerns please feel free to contact us. We're committed to providing our customers with the quality service.