ASSEMBLY INSTRUCTIONS

ITEM #: WF317373 WF317377

WF317374 WF317378


WF317375 WF317380

WF317376


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all hardware and compare with the hardware list below.

ASSEMBLY INSTRUCTION:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy.
- 1. Don't attempt to repair or modify parts that are broken or defective. please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.
- 3. Two persons are required for assembly.
- 4. Approximate assembly time: 1/2 hours.
- 5. Component parts and fittings contained in the box.
 - Please sort out all parts before you begin to assemble the item.
 - This is to make sure you always use the correct part.
- 6. It is STRONGLY RECOMMENDED that you ANCHOR this product.
 - Toppling furniture can cause serious injuries and death.
 - This product has not been fitted with an anchor strap.
 - To prevent your furniture from tipping forward it is strongly recommended.
 - That you securely attach this product to a wall or other solid surface, using the anchor straps Provided and appropriate fixings.



ASSEMBLY INSTRUCTION



Part list & Hardware Ε В Α 1 pc 1 pc 1 pc 1 pc 1 pc 8 pcs F G Н K 1 pc 1 pc 1 pc 2 pcs 2 pcs 2 pcs M N O P 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc R 1 pc 1 pc 2 pcs 2 pcs 2 pcs 1 pc

