









RECTANGULAR GALVANIZED STEEL RAISED GARDEN BED WITH GREENHOUSE KIT



Review assembly drawings carefully and follow the care instructions. Save this document for future reference.






Assemble components on a soft, clean surface to avoid scratching or damaging any surfaces.




Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

No.	GREENHOUSE PARTS	QTY.
1	 Vertical Tube	4
2	 Horizontal Tube	5
3	 Roof Tube	4
4	 Horizontal Tube w/ Torsion Spring	5
5	 Base Side Tube	2
6	 Cover	1


No.	GREENHOUSE CONNECTORS	QTY.
A	 3-Way Elbow Fitting	6
E	 Tee Fitting	4

No.	GARDEN BED PARTS	QTY.
A	 Long Panel	2
B	 Short Panel	2
C	 Corner	4
D	 Bolt	32
E	 Wing Nut	32

TOOLS REQUIRED (not included)



Phillips Screwdriver



Rubber Mallet



CAUTION: SHARP EDGES
USE EXTREME CAUTION
◀ WEAR GLOVES DURING ASSEMBLY ▶



WARNING



CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.


GARDEN BED ASSEMBLY

Review all steps and understand assembly before beginning.

Do not fully tighten hardware until all components have been loosely assembled.



CAUTION: Sharp edges.
Wear gloves during assembly.



! HELPFUL HINTS

- Do not tighten any bolts until the entire unit is loosely assembled. If hardware is tightened too soon, mounting holes may not align and parts may not easily fit together.
- Ensure panels are installed with the rolled edges facing the inside of the bed.

1. Align Corner (C) on the inside edges of Long Panel (A) and Short Panel (B).
2. Insert Bolt (D) through the outside edges of the panels and through the corner panel. Loosely secure the bolts by hand-tightening Wing Nuts (E).
3. After all pieces have been loosely assembled, tighten all wing nuts.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

GREENHOUSE FRAME ASSEMBLY

! HELPFUL HINTS !


Identify and separate all frame tubes and connectors, so they are easy to identify during assembly.

Ensure all tubes get fully inserted into the connectors. A tighter and smaller frame enables the greenhouse cover to slide on easily.

STEP 1

2: 5

4: 5



TIP: To avoid pinching your fingers, angle the tube with the torsion spring so the spring is on the inside the other tube, then align the tubes so they are straight and push them together.

Firmly insert the narrow end of Horizontal Tube w/ Torsion Spring (4) with Horizontal Tube (2) as indicated in the drawing.


Repeat this step with the four remaining sets of tubes.

STEP 2

2+4: 2

5: 2

A: 4




Firmly connect four 3-Way Elbow Fittings (A) to two Base Side Tubes (5) and two sets of Horizontal Tube (2+4) as indicated in the diagram.

STEP 3

1: 4

2+4: 2

E: 4



Firmly insert four Vertical Tubes (1) into the tops of the elbow fittings.

Firmly connect four Tee Fittings (E) to two sets of Horizontal Tubes (2+4).

Align the tee fittings with the tops of the vertical tubes as indicated in the diagram.


Gently tap the tops of the tee fittings to ensure components are tightly fitted.

STEP 4

2+4: 1

3: 4

A: 2



Firmly connect two Elbow Fittings (A) to the last set of Horizontal Tubes (2+4). Then, firmly insert the straight side of four Roof Tubes (3) into the elbow fittings.

Firmly insert the curved ends of the roof tubes into the tee fittings.

COVER INSTALLATION (not shown)



NOTE: The cover is packaged inside out for easier installation.

Unfold Cover (6) on a clean, soft surface that is away from any sharp objects or debris.

Locate the ties on the peak of the cover and tie them to the top of the roof. Carefully unfold the cover over the frame, taking care not to pull too hard as doing so may rip the cover. Then, secure all remaining ties to the frame.

General Use & Care

We cannot foresee every possible scenario or climate in which this greenhouse could be used. Information provided is a basic guide and may not be suited for your particular needs. Use sound judgment when using your new greenhouse.

CHOOSING A LOCATION

Place your greenhouse on raised, level ground to ensure good drainage. Select a location that will receive maximum sun exposure.

Help protect your greenhouse from prevailing winds by placing it next to a structure such as a house or garage.

WATERING

Use mist or the lowest setting on a hose sprayer. Avoid super-cold water as it could shock your plants.

The best time to water plants is in the cooler hours of the morning. Avoid watering plants too late in the evening, as excess moisture promotes plant disease and fungal infections.

Frequently check soil moisture throughout the day; this is especially important in warm weather. If soil becomes too dry, water the soil only. Applying water directly to plants during peak sunlight hours can damage plants.

IDEAL GREENHOUSE TEMPERATURE

The ideal temperatures to maintain inside your greenhouse will depend on the plants you have inside. Always remember that all plants and seeds have preferred growing and germination requirements—research ideal growing conditions for your plants or contact an expert at your local garden center.

COOLING

To lower the temperature inside your greenhouse, open the zippered door(s). You may also consider using a shade cloth (not included).

VENTILATION

It is essential to ensure good air circulation and ventilation year-round. Stagnant air and/or excessive humidity levels may result in fungus and disease, which can damage your plants.

MAINTENANCE AND STORAGE

Hose down your greenhouse using a low-pressure garden hose with a sprayer. Mild dish soap and a soft cloth may be used to help remove stubborn dirt and pollen build-up. Do not use harsh chemical cleaners.

In climates where snow and ice accumulate, disassemble and store in a cool, dry location.

Ensure that the greenhouse is clean and COMPLETELY DRY before storing. Mold and mildew can grow if it is stored wet or even slightly damp.

Use extreme care when disassembling and storing this greenhouse. Carefully remove the cover and fold it. Carefully pull frame tubes out of the connectors. Place all components into the original box or a plastic tote. Use caution when storing the cover; avoid placing it on or near the sharp edges of the frame components.

REPAIRING RIPS AND TEARS

The greenhouse cover is relatively durable, but it is still possible to puncture holes in the material if care is not taken when setting up, taking down, and storing the greenhouse.

A poly patching tape or film (not included) may be used for repairing punctures and tears in the cover. Before purchasing any repair tape or kit, ensure it is suited to the material of your greenhouse cover. Apply as directed by the manufacturer.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY USER ERROR, IMPROPER CARE, THE APPLICATION OF CHEMICAL CLEANERS OR REPAIR KITS.

SAFETY STATEMENTS & WARNINGS

- Anchor the greenhouse to prevent tipping and potential damage from prevailing winds.
- Keep the greenhouse a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not use harsh chemicals or abrasive materials to clean.

The following situations are not cause by faulty materials or workmanship and are not covered by warranty:

- If cover tears due to incorrect frame assembly or being forced onto the frame.
- If the cover tears due to water accumulating on the roof. Water accumulation can cause the cover to stretch and possibly collapse the greenhouse completely.
- If the greenhouse poles or fittings are broken due to high winds or incorrect assembly.

Most cover tears on greenhouses are due to excessive force, environmental conditions, or mechanical damage to the zipper and as such are not covered by warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.