




ITEM #0401989
9 FT. UMBRELLA
MODEL #USB38278 - TAUPE

Français p.4
Español p.7



PARTS LIST

Item	Description	Quantity
A	Finial	1
B	Umbrella	1
C	Bottom pole	1

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-643-0067, 8:00 a.m.- 8:00 p.m., EST, Monday-Friday.



SAFETY INFORMATION

- Assemble on a soft surface, such as carpeting, to avoid scratching the pole finish or tearing the umbrella fabric.
- Crank the umbrella to its closed position during windy conditions. Do not leave the umbrella open in high winds.
- Use a heavy or weighted umbrella base to stabilize the umbrella.

PREPARATION

Before beginning assembly, remove all parts from carton. Compare parts with parts list and diagram on the previous page. If any part is missing or damaged, do not attempt to assemble or use the product. Contact customer service for replacement.

- Estimated Assembly Time: 10 minutes
- No tools required for assembly.

ASSEMBLY INSTRUCTIONS

Step 1

Insert and secure the bottom pole (C) into an umbrella base (not included). Fig.1

Step 2

Slowly crank the handle until slightly open.

Step 3

Connect (B) to (C). Fig.2

Step 4

Crank the handle until the umbrella opens fully. The umbrella is ready to use.




Fig.1




Fig.2



CARE AND MAINTENANCE

- Wash with mild soap and water, rinse with clean water and let air dry.
- Always let the umbrella dry completely before storing.
- Store the umbrella out of extreme weather or high winds. Umbrella covers (sold separately) are recommended when not in use.

ONE-YEAR LIMITED WARRANTY

This warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture, provided your furniture is maintained with care and used only for personal, residential purposes.

Frames are warranted to be free from defects in material or workmanship for a period of one (1) year. Umbrella frames and bases are warranted for a period of one (1) year.

Exclusions: Items used for commercial, contract or other non-residential purposes, display models, items purchased "as is," or items damaged due to acts of nature, vandalism, misuse or improper assembly are not covered. Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills is not covered. Tabletop glass breakage, corrosion or rusting of hardware and damages to frames or welds caused by improper assembly, misuse or natural causes are not covered.

If within the stated warranty period a product is found to be defective in materials or workmanship, the purchaser must contact the manufacturer's Customer Service Department at 1-800-643-0067. The manufacturer, at its option, will repair or replace the defective parts.

Warranty to the original purchaser is non-transferable. All warranty claims require a dated sales receipt. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights. You may also have other rights which vary from state to state.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-800-643-0067, 8a.m.-8p.m., EST, Monday - Friday.

PART	DESCRIPTION	PART#
A	Finial	0401989-E01011
C	Bottom Pole	0401989-F05010

