

## TROUBLE SHOOTING CONTINUED

### PROBLEM

### SOLUTION

	<ul style="list-style-type: none"> <li>Remove the spool and unwind the cutting line, then wind it on neatly again. Replace the spool into the housing.</li> </ul>
Overfeeding	<ul style="list-style-type: none"> <li>Ensure you are cutting with the tip of the line (7 inches (177.8mm) from the spool). Use the edge guide if needed to ensure proper space is maintained.</li> <li>Ensure you are not exceeding a 10° angle as shown in <b>figure N1</b>.</li> </ul>
Line unravels when cap or spool is removed.	<ul style="list-style-type: none"> <li>Make sure to park the lines in holding slots (S2) <b>figure S</b> before removing.</li> </ul>
Battery won't charge.	<ul style="list-style-type: none"> <li>Insert battery into charger until green LED appears. Charge up to 8 hours if battery totally drained.</li> <li>Plug charger into a working outlet. Refer to "Important Charging Notes" for more details.</li> <li>Check current at receptacle by plugging in a lamp or other appliance.</li> <li>Check to see if receptacle is connected to a light switch which turns power off when you turn out the lights.</li> <li>Move charger and tool to a surrounding air temperature of above 40 degree F (4.5°C) or below 105 degree F (+40.5°C).</li> </ul>


## THREE-YEAR LIMITED WARRANTY

Black & Decker (U.S.) Inc. warrants this product to be free from defects in material or workmanship for a period of three (3) years following the date of purchase, provided that the product is used in a home environment. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than BLACK+DECKER and its Authorized Service Centers. A defective product meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways:

The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges. Proof of purchase may be required. Please check with the retailer for its specific return policy regarding time limits for returns or exchanges. The second option is to take or send the product (prepaid) to a BLACK+DECKER owned or authorized Service Center for repair or replacement at BLACK+DECKER's option. Proof of purchase may be required. BLACK+DECKER owned and authorized service centers are listed online at [www.blackanddecker.com](http://www.blackanddecker.com).

This warranty does not apply to accessories. This warranty gives you specific legal rights and you may have other rights which vary from state to state. Should you have any questions, contact the manager of your nearest BLACK+DECKER Service Center. This product is not intended for commercial use, and accordingly, such commercial use of this product will void this warranty. All other guarantees, express or implied, are hereby disclaimed.

**LATIN AMERICA:** This warranty does not apply to products sold in Latin America. For products sold in Latin America, check country specific warranty information contained in the packaging, call the local company or see the website for such information.



Imported by  
Black & Decker (U.S.) Inc.,  
701 E. Joppa Rd.  
Towson, MD 21286 U.S.A.