



Federal Brace
BEAUTIFULLY CRAFTED CONFIDENT SUPPORT

VENDOR #34606

VANITY SUPPORT BRACKET | *Hammam*



HAMMAM VANITY SUPPORT INSTALLATION INSTRUCTIONS



Installation Considerations

Every successful countertop installation begins with good planning and action. Do not wait until the last minute to order your countertop supports, fasteners or adhesives for installation. Make sure that all aspects of the support substructure are considered and discussed to ensure that your countertop installation will be smooth and that your countertop support products will be sufficient.

Note that this installation document should not be considered a specific recommendation to your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.

Characteristics of the Hammam Lavatory Support Bracket

Our Hammam lavatory Brackets are designed to provide the support strength necessary to wall mount a standard vanity in a bathroom setting. The material thickness of the Hammam lavatory Mounting Bracket is 1/4" with 1/2" support arm for the countertop and 2nd 1/2" support arm at 15" height to add a decorative shelf. The Hammam Support comes in black powder coat painted steel materials.

Considerations when Installing Hammam Lavatory Mounting Brackets

The Hammam Lavatory Bracket is designed to tie into the side of the wall stud. This allows the down flange to be placed behind the wall fascia or be hidden in the interior of the wall. The support arm of the bracket will extend out of the wall under the lavatory. It is important to make sure that each support bracket is mounted at the same height to allow for level support of your vanity.

The Hammam is designed to use multiple brackets to support a single vanity. You will want one Hammam on each stud for the length of your counter. Once you have your bracket support locations set up you can mark your holes for drilling and attachment of bracket to the substructure. Make sure that when you fasten the bracket that you check for level in all directions. The brackets vertically level as well as across the top flange. This will give the best possible support result to you lavatory.

You should position the Hammam Lavatory Support Brackets at such a height that it places your vanity at the desired height. Once the brackets are in place you will want to wipe them down to get rid of any hand prints or other debris. Just before installa-

tion of your lavatory you will want to apply adhesive or silicone to the arm extensions to adhere it to the vanity and the shelf.

Final step is to enjoy your work and your new bathroom lavatory! We are thankful that you chose to support your beautiful vanity with Federal Brace brackets. We would be thankful if you would send us images of your new bath room and our brackets under your lavatory We enjoy seeing Federal Brace supports at work.

Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.



For any questions or comments please to contact us by email at customer.service@federalbrace.com or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.



