

## **SHOWER ENCLOSURES**

## **Care and Cleaning of Your ASD Bath Enclosure**

The simplest and preferred method of cleaning your unit is by washing it with clean water and drying with a soft cloth. If soil is still present after drying a non-abrasive cleaner with a pH of seven to eight may be used. Comet Bathroom Cleaner has been tested and is recommended by the Bath Enclosure Manufactures Association (BEMA). Do not use scouring pads, sharp instruments, or acid-based cleaners to clean the unit. Always follow the manufacturer's instructions on the labels of household cleaning products. To protect the finish of you bath enclosure you should only use products recommended for glass and anodized aluminum surfaces by the manufacturer of the cleaning product. If in doubt contact the manufacturer of the cleaning product. Use of harsh cleaners or detergents not specifically recommended for use on anodized metal or glass surfaces may damage your unit.

In some geographic locations extremely high mineral content or other foreign compounds in regular tap water causing excessive acidity or alkalinity can damage or discolor glass and anodized aluminum surfaces with repeated exposure. Etching of glass surfaces by chemical agents is irreversible and appears as a light gray or whitish stain on the glass that is rough to the touch and can not be removed. This is the same effect seen on the glass tumbler washed repeatedly in a dishwasher using strong dishwashing detergent. Spotting is normally the result of mineral buildup on the glass or metal. The anodic coating of aluminum is one of the hardest substances known and is chemically inert to most compounds; however it will be damaged by strong acidic or alkaline solutions. Any chemical that can remove mineral buildup on the surface of aluminum can damage the anodic coating. This will dull or discolor the finish and, on gold units, ultimately cause the color to fade. The most reliable preventative measure to preserve the quality of your bath enclosure unit is to wipe the surfaces day with a soft cloth after each use.

ASD Shower Enclosures A-2