

LED Lighted Medicine Cabinet





# **Series 1: LED Cabinet without Clock**



DHMC3030V3TX W30" x H30" DHMC3026V3TX W30" x H26"



# Series 2: LED Cabinet with Clock





# **Series 2: LED Cabinet with Clock**



#### DHMC4832V4TX W48" x H32"



# Series 3: LED Cabinet with external storage shelf and Night light



DHMC2028V5RX / DHMC2028V5LX W20" x H28" DHMC2432V5RX / DHMC2432V5LX W24" x H32"



DHMC3032V5TX W30" x H32"



DHMC2432V5RY / DHMC2432V5LY W24" x H32"



DHMC3632V5FX / DHMC3632V5FB W36" x H32"



# Series 3: LED Cabinet with external storage shelf and Night light



#### DHMC4832V5FX / DHMC4832V5FB W48" x 32"

#### For easy and safe installation, please refer to the following:

Read all instructions thoroughly before installing the enclosed product. Read and take note of all safety, care and maintenance information.

# PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE DURING PRODUCT OPERATION AND MAINTENANCE.



# INSTALLATION INSTRUCTIONS



# WARNING AND SAFETY INSTRUCTIONS

Before installing your LED Medicine Cabinet fixture, please make sure that you carefully read through this instruction sheet, refer back to them during installation to ensure your product is fitted safely and correctly. Keep these instructions for future use.

## WARNING Risk of Fire and Electric Shock

•All fittings must be installed in accordance with current IEE wiring regulations. If in doubt, consult a qualified electrician.

•Switch off the electrical supply at the main circuit board BEFORE installation and maintenance.

•Suitable for indoor use only. This product should be positioned well away from curtains and fabrics. Never cover the mirror.

•Regularly check the cord, the transformer and all other parts for damage, if any part is damaged the product should not be used.

# **INSTALLATION SAFETY**

•Inspect the product immediately upon receipt for any possible damage during transportation or missing parts. Handle the product with care and protect against knocks to all sides and edges of the glass.

• Ensure there are no hidden pipes or cables in the wall before drilling.

•Wear suitable eye protection when drilling. Take care if drilling on tiled surfaces in case the drill slips.

## CAUTION

The light source of this product is non-changeable light diodes (LED). Do not disassemble the product, as the light diodes can cause damage to the eyes. NOTE:The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture. Do not install this fixture in hazardous locations.



LED Lighted Medicine Cabinet

#### REQUIRTOOLSED



#### PARTS SUPPLIED

2 2	A B A A A A A A A A A A A A A A A A A A		hingecoverX 2-6	
Z-Bar x1	Z-Hook x1 Matching screws x2	for spare		
	Corres D	NUMBER OF	30"*26"/20"*28": Glass shelves x 2	Side panels x 2
Wire caps x3	Anchor x5-7	Round head screw x5-7	Other size: Glass shelves x 3	Side panel lids x4 , Matching screws x10

Email: info@exbriteusa.com























#### **Cabinet embedded Installation Instructions**



\*All diagrams are for reference only.All model dimensions and proportion sposition will vary.



Instructions for assembling the doors and cabinet--Suit for the items which doors and cabinet are separately packaging (considering the huge weight, we suggest installing the cabinet first, then assemble the door with cabinnet as below steps)

1.Insert the hings to the base ,then connect the doors with the cabinet



2.Adjust corresponding screws on the hinge to align the doors, ensure that gaps are even and the doors open and close smoothly





Adjust gap between door and cabinet

3.Insert the wire on the door into the terminal on the cabinet and tighten







# Manual to turn on/off light, dimming, CCT changing with touch switch

- Short touch the button to turn on/off the mirror.
- Adjusting color temperatures (CCT) between warm white and cool white by long - touching the button for seconds.
- Finish setting by withdrawing your finger when the color reaches the one you need.
- Optional to be wired to wall switch by ON/OFF memory function.



- Short touch the button to turn on/off the mirror.
- Long touching the button to adjust the brightness (Dimming).
- Finish setting by withdrawing your finger when the brightness reaches the one you need.



- Mirror begins to be warm and defog after pressing the defogger button.
- Press again to quit the anti fog function.
- Note: The defogger will stop automatically after 60 minutes of continuous operation to prevent any damage caused by prolonged high temperature.



## Manual to setting clock with touch switch

## • Choose and set the clock and temperature mode

-Turn off the light.

-Long-touch button 2 to choose and set the mode when it flash.

There are two clock and temperature modes to choose. A: 12C/12F: Fahrenheit (F) and 12 hours B: 24C/24F: Celsius (C) and 24 hours The default mode is 12C/12F.

# Setting the clock

-Turn off the light to set the clock.

- -Long touch button 1 for seconds, the Hour will flash, then short-touch button1 and 2 to set Hour.
- -Wait for seconds after setting up the Hour, then it will automatically switch to the Minute flash.
- -Short-touch button 1and 2 to set up the Minute.
- -Wait seconds after you finish the time setting, the time will be saved automatically.

# Turn on/off the touch switches' blue background ligth

-In default mode the touch switches is with blue background light, long-touch button 3 to turn on/off the blue background light.

## **Remarks:**

\*The clock shows for 5s, and shift to the temperature showing for 2s, then go back to show the clock.

\*It automatically displays the indoor temperature by auto sensing through the temperature sensor.

\*DO NOT cover the temperature sensor.











# **Night Light**

# Inside Night Light

- The Night Light inside the cabinet will be auto-on/off according to the brightness surrounding when the door be opened.
- Don't cover the night light sensor.

# External Night Light

- -The Night Light will be auto-on/off according to the brightnes surrounding when the rocker switch is kepping turned on.
- If need turn off the night light at night, please turn off the rocker switch manually.
- Don't cover the night light sensor.