

# Widespread Lavatory Faucet SLW-4412 Installation and Service Instructions



Faucet meets ASME A112.18.1/CSA B125.1, NSF/ANSI 61.9, NSF/ANSI 372, WaterSense at 1.0 gpm & 1.5 gpm





**Caution:** Be sure to turn off hot and cold water supplies before installing or servicing faucet.

### **Installation Procedure**

- 1. Push valve bodies through holes in sink from underneath (both valve bodies shall include a red striped hose). Make sure *flange nuts* and *mounting washers* are on underside of sink. Put gasket (LN-129) over *valve body*. Thread escutcheon (LN-128) onto *valve body*. The top of the valve spindle should measure 1-7/8" from mounting surface (See rough in drawing).
- **2.** Thread collar (LN-112) on to valve body until it reaches the escutcheon (LN-128).
- **3.** CRP handle installation: Ensure valve spindle is rotated to the OFF position. Place handle on valve spindle and thread screw (LN-121) into valve.
- **4.** Tighten *flange nuts* and *mounting washers* from underneath sink and secure with *mounting screws* if necessary.
- 5. Install spout (LN-254A) and centerbody (LN-188) through center in sink hole from above sink. Secure spout to sink with washer (LN-138) and nut (SPF-26). Washer (LN-138) flat side should face back of the sink. Thread tee (LN-189) to bottom of centerbody (LN-188).
- **6.** Thread *flex hose adapters* into tee (LN-189) using pipe sealant on the threads. Attach *flex hoses* to *flex hose adapters*.
- **7.** Connect hot supply to left tube and cold supply to right tube using appropriate connectors.
- **8.** Pop-up drain installation:
  - a) Remove pop-up plug, tail piece and flange from the drain body. Make sure that locknut is threaded all the way down onto the body with flat friction washer in middle and beveled washer on top.
  - b) Apply plumbers putty or sealant to bottom of flange.
  - c) Install drain body through drain opening in lavatory and screw flange onto the drain body making sure that the threads are completely engaged for proper sealing and strength of the connection. Apply joint compound to all threaded parts to insure proper seal. Apply putty or teflon tape to tail piece before attaching to drain body.
  - d ) Tighten locknut to compress the beveled flange

- evenly across the bottom of the drain opening taking care not to over tighten the locknut, causing damage to the lavatory. Apply teflon tape (clockwise) on tail piece and thread into outlet of body.
- e) Insert pop-up plug and pivot rod into body and tighten retaining nut until the ball is seated on the ball washer.
  - Note: The pop-up plug can be installed either in the removable or non-removable position, depending on the location of the hole located in the guide at the bottom of the plug.
- f) Slide the pivot rod through one side of the spring clip, then the appropriate adjustment hole and then other side of the spring clip.
- g ) Insert lift rod through faucet housing and the top of the lift strap and secure it in place by tightening the screw

Note: To insure proper operation of lift rod and pop-up, some adjustment of the linkage may be required.

There are two possible adjustment points:

- 1) lift strap to lift rod
- 2) lift strap to pivot rod
- 8. It is very important to thoroughly flush the supply lines to prevent foreign matter, i.e. copper chips, sand, stones, etc. from damaging the sealing surfaces of cartridge.

  Remove aerator and open hot and cold to full open then open both supplies. Let water run through hot and cold long enough to flush supply lines thoroughly. Shut off faucet and replace aerator. Check for leaks.

## Replacing cartridge (KN-113 or KN-114):

- 1. Remove plug button (LN-243H or LN-243C), loosen Phillips head screw (LN-121) and remove handle (LN-177).
- 2. Remove collar (LN-112) by turning counter clockwise. Caution: Do not use wrench as this may damage the surface finish.
- **3.** Place wrench on cartridge hex nut (KN-113, KN-114). Turn wrench counterclockwise until cartridge is removed.
- **4.** Install new cartridge. Turn cartridge with wrench until cartridge does not turn easily then turn 1/4 to 1/2 turn further. Reassemble handle in reverse fashion.

#### **Dimensions** Carrington Two Handle Widespread Lavatory Faucet, SLW-4412 8"(203 mm) min 🗔 - 5-13/16" -1-9/16" (40 mm) 16"(406 mm) max! (148 mm) 2-5/16" dia (59 mm) 7-1/4" 4" (102 mm) min 7-1/8" (184 mm) (181 mm) <sub>4-5/32</sub>" 2-7/16" (106 mm) 1-7/8" (62 mm) (48 mm) Deck thickness 1-3/8" (35 mm) max-Hole size - 1" dia 5/8" dia 1-1/2" (38 mm) min Hole size (25 mm) (16 mm) 1-5/8" (41 mm) max 1-1/4" (32 mm) 3/4" (19 mm) 1/2"-14 NPSM Flexible hose Note: Dimensions subject to change without notice

#### Parts Assembly Carrington Two Handle Widespread Lavatory Faucet, SLW-4412 Valve cartridge (1) KN-114 LN-243C (1) LN-243H (1) L-26 O-ring (2) (plug button) L-26 (2) LN-112\* Collar (2) LN-121 (2)LN-121 Handle screw, M4x12, SS, panhead (2) LN-128\* Escutcheon, widespread (2) (2)Gasket, Escutcheon (2) LN-129 (2)LN-138 Washer (2)Handle kit LN-150 O-ring (2) LN-177\* Cross handle (2) (2 handles) (2)LN-185 Gasket, spout LN-188 Centerbody KN-114 P-108CL12 Centerbody tee LN-189 LN-243C Plug button, porcelain (cold) KN-114 Plug button, porcelain (hot) LN-254A LN-243H LN-254A\* Spout Aerator insert Lift rod (for pop-up drain assembly) P-108CL12\* 2.2 gpm SPF-26 Nut, Hex (centerbody) LN-185 LN-188 WSF-CRP-KIT Handle kit (qty 2 handles) LN-138 \*For Decorative Finish Faucets add suffix to parts SPF-26 Mounting screws marked with an asterisk as follows: LN-150 Suffix -STN Radiance® satin finish Mounting washer Flange nut LN-189 Flex hose adapter Flex hose Aerator Part Number (flow regulator) Standard Aerator 2.2 gpm (8.3L/min) P-26\* RL-154LR\* 1.5 gpm (5.7L/min) LN-741\* Grid drain Pop-up drain assembly 1.0 gpm (3.8L/min (optional) (without lift rod)

**WARNING:** This product can expose you to chemicals including lead, which is known to the state of California to cause cancer, birth defects, or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Symmons Industries, Inc. ■ 31 Brooks Drive ■ Braintree, MA 02184

Phone: (800) 796-6667 • Fax: (800) 961-9621

Website: symmons.com • Email: gethelp@symmons.com

