


Parts Identification




Note: Do not obstruct the air inlet and/or outlet.


Operation Instructions

1. Install the Handle


1) Get the handle from the bottom packing foam.



2) Install the handle as illustrated below, please note to align the holes on the handle with the holes on the dehumidifier.



3) Use a screwdriver to tighten the screws until the handle is firmly attached to the dehumidifier.



2.Position Your Dehumidifier

- For optimal outcomes, use your dehumidifier in a confined space.
- Shut all entryways and windows.
- Position it clear of obstructions and avoid anything that could obstruct airflow in or out of the dehumidifier.

Note: Place the dehumidifier on a flat surface to minimize vibration or noise.

3. Setting up the Drainage System


3.1 The dehumidifier comes equipped with an internal pump for drainage, specially designed to handle upward drainage needs.

Note: To prevent any leakage, please ensure the drainage height does not exceed a distance of more than 16.4 feet from the drainage outlet.

3.2 Please connect the provided drain hose to the outlet for secure and effective drainage.

Note: If an alternative drainage hose(inner diameter is 0.197 inches) is used, please ensure it is compatible with the drainage outlet to avoid any risk of leakage.

3.3 During the drainage process, please keep the hose unobstructed and free from twists or kinks. This will enable the smooth removal of condensate water.



4. Plug in Electrical Cord

IMPORTANT

Please let the dehumidifier stand upright for **24 hours** before plugging in for the first time. During the shipping process, the dehumidifier may have been subjected to tilting or even placed upside down, which can cause the oil in the compressor to become unsettled. Failure to let the dehumidifier stand upright for the recommended duration can negatively impact its performance or even shorten its lifespan. Hence, kindly make sure to follow this crucial step before using the dehumidifier.

To properly operate the dehumidifier, please plug it into a GFCI-protected 115-volt outlet with a rating of at least 16 amps. Uncoil the power cord and securely connect it to an appropriate outlet.

Note: When the dehumidifier is first plugged into AC power, the control panel display will light up for a second, which is part of the dehumidifier's self-diagnosis procedure and no action is required. This indicates that the dehumidifier is functioning correctly and ready to operate effectively. You will still need to press the POWER button to turn the dehumidifier on. If not been operated for over 50 seconds, the control panel will become dim until pressed buttons again.