


# WaterdrOp

## Triple-Stage Undersink Water Filtration System WD-TSA-10 system | Installation Instructions

**WARNING** Please read it carefully before installation.



### Specifications

Operating temperature	2-38 °C/35-100 °C
Working pressure	10-125psi (0.7-8.6bar)
Flow rate	1gpm
Filter capacity	WD-10PP: up to 6 months
	WD-10GC: 8-12 months
	WD-10CT: 12-18 months
Feed water requirement	Municipal tap water

**NOTE:** The service life mentioned above is subject to chlorine reduction. Actual result varies according to the local water quality.


### Precautions

- Do not use it with water that's microbiologically unsafe or of unknown quality without adequate disinfection.
- For use only with cold water.
- Do not freeze the filter, as this can cause cracking and water leakage.
- Do not allow children under 3 years old to have access to small parts during installation of this product.
- This installation must comply with all applicable state and local regulations.
- Turn off the water supply while replacing the filter.

### Installation of the filter system


#### Tips: How to disconnect the quick-connect?

Use your thumb and index finger to press down on the lock sleeve. Use your other hand to pull out the hose from the fitting.  
**NOTE:** Please do not pull out the tubing directly, or else it will damage the fitting and cause leakage.






#### Step 1: Fix the filter head and the filter

- Paste the assistant label to finish drilling.
- Mount the water filter at least 2 inches above the ground to facilitate easier filter replacement.
- Install the screw and reserve enough space to hang the filter.
- Hang the filter system on the screw.



#### Step 2: Connect the water supply (cold water only)

- Shut off the water supply. Remove the faucet hose. (Figure 1)
- Connect the inlet hose to the cold water valve. (Figure 2)
- If the angle valve outlet is 3/8", it can be directly connected to the water supply. (Figure 2)
- If the angle valve outlet is 1/2", connect it with a No.1 converter at first. (Figure 3)



#### Step 3: Connect to the faucet

- If the angle valve outlet is 3/8", it can be directly connected to the water supply. (Figure 4)
- If the angle valve outlet is 1/2", connect it with a No.2 converter at first. (Figure 5)

Figure 4





Figure 5




**NOTE:** If a female threaded connector is needed, please contact our service team for help.

#### Step 4: Connect to the filter system


Connect the inlet hose and the outlet hose to the filter head. Make sure the hoses hit the bottom of the filter head.

**NOTE:** When the hose is tightly inserted, there will be a 1/8 inch gap between the hose and the filter head, which is designed for easy replacement and won't affect the sealing performance.




#### Step 5: Flush the filter and check the leaks

- Flush the filter for 5 minutes before use.
- If water leakage occurs, turn off the water supply. If the water leakage is occurring at position 1 and 2, wrap Teflon tape on the external thread. If the water leakage is occurring at position 3 or 4, insert the quick-connect fitting to the end and make sure the hoses hit the bottom of the fitting.



### Filter replacement

- It's recommended to turn off the water supply and turn on the faucet to release the water pressure.
- Rotate 1/4 turn to the left to remove the filter.
- Take out the new filter and remove the protective cap.
- Rotate 1/4 turn to the right to install the filter. Ensure that the filter's triangle mark is aligned with the connection mark.
- Turn on the cold water valve and flush for 5 minutes.



### Frequently asked questions

#### Q: What should I do if water leaks after installation?

A: In the event of water leakage, turn off the water supply. If the water leakage is occurring at the thread, wrap Teflon tape on the external thread. If the water leakage is occurring at the quick connection position, insert the quick-connect fitting to the end and make sure the hoses hit the bottom of the fitting. Contact us for solutions if the water leakage persists.

#### Q: Why doesn't the TDS value lower after filtration?

A: The main purpose of this waterdrop filter is not to remove TDS. TDS stands for total dissolved solids, and it is basically composed of inorganic salts and a small amount of organic matter. The filter can remove harmful substances while keeping beneficial trace elements. Please choose Waterdrop RO system if you are looking for physical removal of TDS.

#### Q: When should I replace the filter?

A: The filter's service life is related to the water quality. If the flow rate is significantly reduced or if the water has a peculiar smell, we suggest that you replace the filter. The recommended service life of the filter is as follows: The PP filter has a 6 month lifetime; the GC filter has an 8-12 months lifetime; the CT filter has an 12-18 months lifetime.

#### Q: What substances can the filter reduce?

A: Our premium coconut carbon block filter has been tested by an independent laboratory against NSF standards. It can effectively reduce chlorine, taste and odor, cysts, hydrogen sulfide, and other heavy metals.

#### Q: What is the difference between the WD-TSA system and the WD-TSB system?

A: The WD-TSA system does not come with a faucet. It will connect to your existing faucet. Meanwhile, the WD-TSB system comes with an additional water faucet.

### 1-year quality assurance

All mechanical devices with moving parts have a normal life span and will need to be replaced periodically. For this reason, mechanical devices such as water fittings, filter head, and faucets have a limited replacement assurance of 1 year. No assurance is given as to the service life of any filter cartridge, as the service life will vary based on local water conditions and water consumption.

If the product proves to be defective within 1 year from the date of purchase, please contact our customer service department. During the assurance period, we will replace or repair any part that is deemed to be defective if the product has not been subjected to tampering, alteration, or improper use after delivery, and has not been repaired by the manufacturer.

We do not make any promises in the event of misuse, use in abnormal temperature conditions, conditions outside those listed in the operating parameters, or use in commercial operations.

# WaterdrOp

Filter Better Live Healthier

### Manufacturer Technical Support

Tel: 1-888-352-3558 (U.S.)  
E-mail: UWF@waterdropfilter.com



V041

### 印刷品技术要求

- 工艺要求 覆光膜 覆亚膜 覆UV油 覆塑油 过油 丝印 晒射
- 材质要求 80#双胶纸, 风琴折
- 颜色要求 单黑印刷
- 版面要求 网点清晰, 角度准确, 无重影; 覆膜表面平整, 无褶皱; 纸张材质正确, 切边整齐, 压线深浅适中。  
套印误差: 平版印刷品≤0.1mm, 柔性印刷品≤0.2mm  
模切尺寸误差: 成品偏差±0.4mm, 模切位置尺寸±0.8mm  
图案位置偏差: ±0.5mm

图像颜色请依据数码稿印刷  
请不要擅自变更来稿件, 如须修改, 请联系伊可普做有关决定



### 青岛伊可普电器有限公司包材设计图纸

品牌	Waterdrop	工厂型号	EWf-1008
包材文件名称	03070201008-8016BUA WD-TSA-10-整机说明书-UA-V041		
尺寸规格	见图纸标注	比例尺	1:1
单位	mm	页数	
设计师	张鑫龙	审核日期	2024.4.12

2021.11.26 增加客服24H7D365信息  
2024.4.12 改LOGO, 优化排版

DCR变更  
(变更日期+变更描述)