




INSTALLATION PROCEDURE




MEASURE THE DISTANCE
BETWEEN TWO POINTS

①



PUNCH HOLES IN THE MEASURED
POINTS AND DRIVE THE SCREWS




②



INSTALL Z-BAR


③

④



ACCURATELY
CONNECT WALL
WIRING

SPECIFIC OPERATION



Button 1:

The first time you click, turn on the light
short press, Open the warm light
short press, Open the neutral light

Three different light sources can be switched at the touch of a switch



Button 2:

when three-color light on, this key is valued to below function:

The first long press brightens the light.

The second long press dimmed the light.



Button 3:

With the lights on:

Click the defogging button, The defogging function is in operation