


Installation Instructions, Post Base

6x6 shown
with optional
2-3/8 Star
(56623-sold
separately)



56604 4x6 (4x6-PB-LS)
51704 4x6 (4x6-PB-IW)
56605 10x10 (10x10-PB-LS)
56607 4x4 (4x4-PB-LS)
51707 4x4 (4x4-PB-IW)
56608 6x6 (4x6-PB-LS)
51708 6x6 (4x6-PB-IW)
56609 8x8 (8x8-PB-LS)
51709 8x8 (8x8-PB-IW)

this instruction illustrates 6x6 Post Base installation.
All Post Bases will be installed the same.

Laredo Sunset shown




OZCO BUILDING PRODUCTS



Printing Documents from ISSUU

Unfortunately, there is currently no way to print content directly through issuu. To print a publication, you will need to download it and print it from your computer.




Laredo Sunset & Ironwood




Laredo Sunset
(566XX series)

2 great styles
Same functionality
choose your
connection lifestyle
both styles available for
most products




Ironwood
(517XX series)









6x6 Post Base Kit (6X6-PB-LS)
56608



4x6 Post Base
56604




4x4 Post Base (4x4-PB-LS)
56607





Overview-Laredo Sunset


Installation Instructions, Post Base




10x10 Post Base (10x10-PB-LS)
56605




8x8 Post Base (8x8-PB-LS)
56609



Overview-Laredo Sunset




10x10 Post Base (10x10-PB-IW)
51705





Overview-Ironwood

Installation Instructions, Post Base





4x4 Post Base (4x4-PB-IW)
51707






6x6 Post Base (6x6-PB-IW)
51708



8x8 Post Base (8x8-PB-IW)
51709




Overview-Ironwood

Installation Instructions, Post Base





V2.00 - Installation Instructions, Specifications and Project Plans are effective 9/6/2016 . This information is updated periodically and should not be relied upon after 2 years from 9/6/2016 . Please visit OZCOBP.com to get current information.

mount base to surface




6x6 shown





choose fastener that suits your application

step 1

Installation Instructions, Post Base










6x6 shown



step 2



Installation Instructions, Post Base



step 3

Installation Instructions, Post Base



V2.00 - Installation Instructions, Specifications and Project Plans are effective 9/6/2016 . This information is updated periodically and should not be relied upon after 2 years from 9/6/2016 . Please visit OZCOBP.com to get current information.



optional accessory

Installation Instructions, Post Base




6x6 shown



additional instructions

- center post as shown in previous steps
- install 1 compression plate with fasteners
- remove, reposition & reinstall post/compression plate as shown with **plate facing wall**
- complete assembly as shown

this procedure applies to all OZCO Post Bases & Post Anchors utilizing compression plates (56607 shown)



Special Instructions-mounting next to wall

4x4 shown