



User Manual DC-15

Before first use, completely charge the battery

Safety precautions

- Do not use in the immediate vicinity of inflammable materials or gases.
- Do not touch LED portion of light after an extended period of use. Temperature can reach or exceed 40°C
- Keep the lens and surrounding areas free from obstructions during use.
- Recommended to only use the accessories included with the product for recharging the light.
- Keep the lamp out of reach of unauthorized persons, especially children.
- Do not point the light directly in your own or any other person's or animal's eyes.
- Inspect charging cable and port for damage before use. Do not use if damaged.
- Keep charging port cover in place when not in use to keep out water, dirt & dust.

Lamp design and accessories

- USB power bank
- Battery life meter
- IP65 water-resistant
- LED reflecting bowl
- Swivel handle and stand

Technical data

- 3.7V – rechargeable battery, Lithium 3.7V 2500mAh
- 10W Chip on Board (COB) LED
- Lumen Rating: Approx. 1,000LM
- Ambient temperature: -10° to +45°C
- Usage period: Approx. 3.0 hours at 100% Brightness
- Charging period: Approx. 5h (at 25°C)
- Protection class: III
- Charging input: 5V max. 1000mA

Recharging

- Completely charge the battery before first use and completely discharge the battery before recharging.
- For ideal battery life expectancy, it is recommended to charge at least once every 3 months.
- Charge with a USB port charger or other 5-volt output USB device (1000 mA maximum, not included) using included USB cable.
- Battery charge status can be monitored by viewing the LED battery status indicator. The battery is fully charged when all three LEDs are lit.

Usage

On/Off & Brightness Button:

- 1: Press One time: 100% brightness
- 2: Press Two times consecutively: 50% brightness
- 3: Press Three times consecutively: 10% brightness
- 3: To turn off, press four times consecutively or once if the light has been on for more than 5 seconds

NOTE:

Be sure to properly dispose of used battery.