



Installation Instructions





For normal household use, installation is easily performed without professional assistance.






1. Register your filter using the QR code on the packaging or by going to www.filterwarranty.com. Set reminders for cleaning your air filter.
2. Remove your old disposable filter.
3. Install your air-Care filter in the same space.
4. Refer to the filter label for air-flow direction when installing.

For cleaning instructions, please see the following pages

Cleaning Instructions

Cleaning is quick & easy. When cleaned as directed, your electrostatic air filter will give you many years of trouble-free use. Failure to properly clean the filter may lessen filter effectiveness, and as with any air filter, it is possible for an excessive dirt buildup to cause air flow resistance sufficient to damage other ventilation components. Depending on your specific situation the filter should be cleaned every 4-6 weeks.

<p>1. Simply remove the air filter.</p>	
<p>2. Flush with water in opposite direction of air flow arrows.</p>	 
<p>3. Turn filter and wash with airflow.</p>	

<p>4. Spray Air-Care's C.E.F. Spray (Cleans Electronic Filters) to help with stubborn dust and stains(Model SACH0062).</p>	
<p>5. Rinse thoroughly to remove remaining dirt</p>	
<p>6. Drain excess water, let filter air dry for approximately 20 minutes</p>	
<p>7. Once dry, apply Air-Cares UOK(Ultra Odor Kill) Deodorizer for odor control(Model SACH0064). Can be repeated as desired</p>	
<p>8. Once all steps are completed, re-install filter</p>	
<p>For a video overview, click on the following hyperlink:</p>	<p>https://www.youtube.com/watch?v=WpdigS5-Ygo</p>