


Arch Dimension Guide

Arch Size	Fits Window Width in Inches		Fits Window Height in Inches	
	From	To	From	To
22	20 1/4	23 3/4	10 1/8	11 7/8
24	22 1/4	25 3/4	11 1/8	12 7/8
26	24 1/4	27 3/4	12 1/8	13 7/8
27	25 1/4	28 3/4	12 5/8	14 3/8
28	26 1/4	29 3/4	13 1/8	14 7/8
30	28 1/4	31 3/4	14 1/8	15 7/8
32	30 1/4	33 3/4	15 1/8	16 7/8
33	31 1/4	34 3/4	15 5/8	17 3/8
34	32 1/4	35 3/4	16 1/8	17 7/8
36	34 1/4	37 3/4	17 1/8	18 7/8
38	36 1/4	39 3/4	18 1/8	19 7/8
39	37 1/4	40 3/4	18 5/8	20 3/8
40	38 1/4	41 3/4	19 1/8	20 7/8
42	40 1/4	43 3/4	20 1/8	21 7/8
44	42 1/4	45 3/4	21 1/8	22 7/8
45	43 1/4	46 3/4	21 5/8	23 3/8
46	44 1/4	47 3/4	22 1/8	23 7/8
48	46 1/4	49 3/4	23 1/8	24 7/8
50	48 1/4	51 3/4	24 1/8	25 7/8
51	49 1/4	52 3/4	24 5/8	26 3/8
52	50 1/4	53 3/4	25 1/8	26 7/8
54	52 1/4	55 3/4	26 1/8	27 7/8
56	54 1/4	57 3/4	27 1/8	28 7/8
57	55 1/4	58 3/4	27 5/8	29 3/8
58	56 1/4	59 3/4	28 1/8	29 7/8
60	58 1/4	61 3/4	29 1/8	30 7/8
63	61 1/4	64 3/4	30 5/8	32 3/8
66	64 1/4	67 3/4	32 1/8	33 7/8
69	67 1/4	70 3/4	33 5/8	35 3/8
70	68 1/4	71 3/4	34 1/8	35 7/8
72	70 1/4	73 3/4	35 1/8	36 7/8

How to Measure Window Arch



Step 1: Measure the base width inside the window opening.

Step 2: Measure the tallest point height inside the window opening.

Note: Tallest height should be half of the width size (Perfect Arch). If window size can accommodate two size ranges, it is recommended to use the larger size for a more secure fit.

Window Arch Size Considerations

	Width	Height
<i>Maximum:</i>	73 1/2"	36 5/8"
<i>Minimum:</i>	20 1/2"	10 3/8"
<i>Min. Window Depth:</i>	2 1/2"	