
#### **Product Dimensions**

# 30" Model 161/2" (42 cm) (15.2 cm) 111/2" (29.2 cm) 23/8" (6 cm) (2.5 cm) 2915/16 26<sup>1</sup> 103/4<sup>11</sup> (66 cm) (76 cm) (27.2 cm) (50 cm) A. 30" Cabinet inner dimensions


MIN: 27<sup>15</sup>/<sub>32</sub>" (69.75 cm) MAX: 28<sup>13</sup>/<sub>64</sub>" (71.65 cm)

## **Cabinet Dimensions**



- A. 12" (30.5 cm) min. upper cabinet height
- B. 30" cabinet width: min. 27.4" max 28.5" 36" cabinet width: min. 33.9" max 34.5"
- C. 24" (61.0 cm) min. from electric cooking surface, 27" (68.6 cm) min. from gas cooking surface, 36" (91.4 cm) suggested max. bottom of cabinet to cooking surface
- D. 12" (30.5 cm) cabinet depth
- E. 15" (38.1 cm) min. clearance upper cabinet to countertop
- F. 36" (91.4 cm) base cabinet height

#### 36" Model



A. 36" Cabinet inner dimensions MIN: 33<sup>15</sup>/<sub>32</sub>" (86.2 cm) MAX: 34<sup>11</sup>/<sub>16</sub>" (88.1 cm)

**IMPORTANT:** Mount this hood so that the bottom edge above the cooking surface is at 27" (68.5 cm) minimum if a gas range is used, or at 24" (61 cm) if an electric range is used. The suggested maximum distance is 36" (91.4 cm). For household use, please read the installation manual for specific application. Check your cabinet dimensions prior to selecting your vent hood.

# Venting Requirements (vented models only)

- Vent system must terminate to the outside, except for nonvented (recirculating) installations.
- Do not terminate the vent system in an attic or other enclosed area.
- Do not use a 4" (10.2 cm) laundry-type wall cap.
- Use metal vent only. A rigid metal vent is recommended.
- Plastic or metal foil vent is not recommended.
- The length of the vent system and number of elbows should be kept to a minimum to provide efficient performance.

### For the most efficient and quiet operation:

- Use no more than three 90° elbows.
- Make sure there is a minimum of 24" (61.0 cm) of straight vent between the elbows if more than one elbow is used.
- Do not install two elbows together.
- The vent system must have a damper.
- Use clamps to seal all joints in the vent system.
- Use caulking to seal exterior wall or roof opening around the cap.
- The size of the vent should be uniform.