

KOHLER® Roughing-In

K-T396, K-T397 DEVONSHIRE® RITE-TEMP® PRESSURE-BALANCING BATH/SHOWER VALVE TRIM

Product Information

Applicable product:	
Shower and valve trim with K-304-K Rite Temp valve (shown)	K-T396-4
Valve trim only with selected Rite-Temp® valve	K-T397-4
Rite-Temp® valve must be ordered to complete faucet.	

Lever handle is ADA compliant. **ADA**

Required accessories:	
Rite-Temp® valve without stops OR	K-304-K
Rite-Temp® valve with stops OR	K-304-KS
Rite-Temp® valve with PVC connections OR	K-304-KP
HiFlow Rite-Temp® valve with integral stops	K-306-KS
HiFlow Rite-Temp® thin wall installation kit*	88526

* Required when using the K-306-KS valve in a fiberglass or acrylic installation.

Optional Accessories:

Deep roughing-in kit for Rite-Temp® valve (lever handles)	1030932
---	---------

Installation Notes



WARNING: Risk of damage to the K-306-KS valve assembly. When using the K-306-KS valve in a fiberglass or acrylic installation, use the thin wall installation kit (88526).

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout, if used.

