


PACKAGE CONTENTS

Revised 2015-12-24

Part	Description	Quantity
A	Crossbar	1pc
B	Green Ground Screw	1pc
C	Hex Nut	4pcs
D	Nipple	1pc
E	Lock Washer	2pcs
F	Canopy Chain Loop	1pc
G	Canopy Lock Ring	1pc
H	Fixture Chain	1pc
I	Ceiling Canopy	1pc
J	Lock Ball	6pcs
K	Shade Stop	1pc
L	Shade Holder	1pc
M	Cap	1pc
N	Fixture Loop	1pc
O	Stem Assembly	1pc
P	Side Arm	3pcs
Q	Tube	1pc
R	Center Stem with Fixture Canopy	1pc
S	Shade	1pc
T	Socket Assembly	1pc
U	Finial	1pc



WARNINGS AND CAUTIONS

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

PREPARATION

Please go to www. quoizel. com for product cleaning tips. Go to the **Care + Maintenance** selection.

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.


Light Source: (4) Medium Base 100W Maximum, Alternate (4) 23W CFL Bulbs

Estimated Assembly Time: 30-45 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.


STEP 1 :

- Carefully unfold all Support Arms to proper locations .
- Locate the Tube over the Center Stem with the Studs end on the top. Thread the end of the Center Stem into the Hex Coupling on the center of the Socket Assembly. Hand tighten until snug. Please adjust the Tube to make sure Studs on the Tube and Support Arms are lined up before tighten.




STEP 2 :

- Locate Side Arms and match the holes on them with Studs on Center Stem and Support Arms. Secure the Side Arms by threading Lock Balls onto the Studs. Hand tighten until snug.




STEP 3 :

- Thread the Fixture Loop onto the Nipple on the top center of the Fixture Canopy. Hand tighten until snug.



STEP 4:


- Secure the Crossbar onto the Outlet Box with Outlet Box Screws. Tighten until snug.



STEP 5:


* Plier is required on this step.

- Thread one Hex Nut onto top end of the Nipple.
- Place one Lock Washer over the top end of the Nipple and then thread the Nipple into the center lock hole of the Crossbar.
- Using plier, thread the Hex Nut against the crossbar and hand tighten until snug.
- Thread another Hex Nut onto the bottom end of the Nipple.



STEP 6:


- Adjust the Fixture Chain to your desired length by removing the links if needed.
* Please note that depends on chain material thickness, you might be required to use chain pliers to spread links open.
- Pull the supply wires through the Fixture Chain alternating links. And then pull the wires through the following components in turn:
Canopy Lock Ring, Ceiling Canopy, Canopy Chain Loop, Lock Washer, and Nipple.
- Place Lock Washer over the end of the Nipple and thread the Canopy Chain Loop onto the end of the Nipple.
- Using plier, thread the Hex Nut against the Canopy Chain Loop and tighten until snug.
- Attach one end of the Fixture Chain onto the Fixture Loop and attach the another end of the chain onto the Canopy Chain Loop.
- Refer to Step 7 – Wire Connections to connect wires.
- Push the Ceiling Canopy upward over the Outlet Box.
- Thread the Canopy Lock Ring onto the Canopy Chain Loop and tighten until snug to secure the Ceiling Canopy.



STEP 7:


- Use standard wire connectors (not included) to make all wire connections. (Connectors are not included with fixture.) Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into outlet box.

Note: If the electrical wire is going to be cut shorter than provided you will need to identify the "L" line wire and the "N" neutral wire before you cut the excess wire off. One is labeled N and the other labeled L. To do this separate the "L" line wire and the "N" neutral wire as far as you need to. Re-label the wire near where you want to make the cut. Be sure to mark the wire on the side of the fixture and not on the excess wire being cut and removed.




STEP 8:

- a. Thread short nipple end of the Stem Assembly into the Hex Coupling underside of Socket Assembly and hand tighten until snug.




STEP 9:

- a. Thread the Hex Nut onto the end of the Center Assembly and adjust to proper location for the rest components.
- b. Locate the Shade Stop, Shade and Shade Holder over the end of the Stem Assembly and secure with the Hex Nut. Hand tighten until snug.



STEP 10:

- a. Locate the Cap over the end of the Nipple and secure with the Finial. Hand tighten until snug.



STEP 11:

- a. Install correct bulbs referring to fixture markings and/or labels for maximum wattage.

Your installation is completed now. Restore electricity. Retain this sheet for future reference.