
CM979000TX 4PC CONSOLE/MIRROR/ SCONCE PAIR SET - CARSHAW Assembly Instructions




For assistance with assembly contact: Southern Enterprises, Inc. Customer Service 1-800-633-5096 service@seidal.com wwww.seidal.com







4PC CONSOLE/MIRROR/ SCONCE PAIR SET - CARSHAW Parts List


Please review all parts and hardware before disposing of any packaging. Call Customer Service if missing hardware. Do not return to store/retailer. Using a screw that is too long will cause damage. Before beginning assembly, separate each type of screw. Carefully study the screw diagrams below. You may receive extra hardware with your unit.





4PC CONSOLE/MIRROR/ SCONCE PAIR SET - CARSHAW Assembly Instructions






	1. Place table upright on the floor.
Figure 5	 Screw stabilizer cap (G) into the leg stabilizer bar (F). Tighten securely.
Figure 6	The table is completely assembled.
** We recommend that you save the Allen wrench (I) and periodically tighten all bolts. Please make sure all bolts are placed in their proper positions and then are tightened securely to ensure your safety.	 ** Weight restriction: 40 lbs. ** Do not sit, stand, or climb on table-top. ** Intended for indoor use only.


4PC CONSOLE/MIRROR/ SCONCE PAIR SET - CARSHAW Installation Instructions

Mount the mirror and two wall sconces on the wall, as following steps.


- 1. The products should be mounted to studs in the wall if possible. If studs are not available, the products should be mounted into drywall using the plastic anchors and screws provided.
- 2. **If mounting to studs**, screw mounting screws directly into studs. Attach products to the wall by placing the pre-installed hooks (see back of products) on to the screws. Make sure screws are securely in place.
- 3. If mounting to drywall, drill 3/16" pilot holes into drywall. Insert plastic anchors into pilot holes. Insert the screws provided into the plastic anchors. Attach products to wall by placing the pre-installed hooks (see back of products) on to the screws. Make sure screws are tightened securely in place.

CAUTION: PLASTIC WALL ANCHORS AND SCREWS MUST BE USED WHEN MOUNTING PRODUCTS TO DRYWALL.





Plastic wall anchors and screws must be used when mounting products to drywall.



Phillips screwdriver (not provided)

Drill (not provided)



Hammer (not provided)

Parts Replacement Form				
Customer Information				
Name				
Address				
City/State/Zip Code				
Phone Number				
Please indicate where	you purchased this item: S	tore/Website/Catalog		
Please indicate color/size/style number:				
Style No P	Parts Letter	Parts Description	Quantity Needed	

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise. Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am – 4pm Mon-Fri Central time if you have product issues or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service 1-800-633-5096 service@seidal.com Southern Enterprises, Inc. 600 Freeport Parkway, Suite 200 Coppell, Texas 75019