

INSTALLATION INSTRUCTIONS

1. Remove all packaging material. This includes the foam base and all adhesive tape holding the freezer accessories inside and outside.
2. Inspect and remove any remains of packing, tape or printed materials before powering on the freezer.

CAUTION

Risk of Fire or Explosion due to puncture of refrigerant tubing. Flammable refrigerant used. Handle with care when moving freezer to avoid either damaging the refrigerant tubing or increasing the risk of a leak.

ADJUSTING YOUR FREEZER

- Your freezer is designed for freestanding installation only. It should not be recessed or built-in.
- Place the freezer on a floor strong enough to support it fully loaded.
- When moving the freezer, never tilt it more than a 45° angle. This could damage the compressor and the sealed system.
- If the freezer is tilted, let it stand in an upright position for at least 24 hours prior to plugging. This is to allow the refrigerant to settle.

PROPER AIR CIRCULATION

- To assure your freezer works at the maximum efficiency it was designed for, you should install it in a location where there is proper air circulation, plumbing and electrical connections.
- The following are recommended clearances around the freezer:
Sides.....4 in.
Back.....4 in.

ELECTRICAL REQUIREMENT

- Make sure there is a suitable power outlet (115 volts, 15 amps outlet) with proper grounding to power the freezer.
- Avoid the use of three plug adapters or cutting off the third grounding pin in order to accommodate a two plug outlet. This is a dangerous practice since it provides no effective grounding pin for the freezer and may result in shock hazard.

INSTALL LIMITATIONS

- Do not install your freezer in any location not properly insulated or heated, e.g. garage, etc. Your freezer was not designed to operate in temperature settings less than 55° or more than 90° Fahrenheit.
- Select a suitable location for the freezer on a hard, even surface away from direct sunlight or heat sources, e.g. radiators, baseboard heaters, cooking appliances, etc. Any floor unevenness should be corrected.

USE OF EXTENSION CORDS

- DO NOT use extension cords because of potential safety hazards under certain conditions.