



LANDSCAPE WALL | 4-IN X 11.5-IN WALL BLOCK

INSTALLATION INSTRUCTIONS



1. Prepare Wall Location

Start by digging a shallow trench 4" (102mm) deep by 12" (305mm) wide. Cut through and remove any sod, roots or large rocks. For organic loam soils, dig 4" (102mm) deeper and add a leveling pad of sand or gravel. Compact and level the soil to receive the first course of Wall Block.



2. Place & Compact Backfill

Place and level the first unit. Level each additional unit on the base course as you place it, making sure that the outside edges touch. If your wall contains both straight and curved areas, start with a straight area and build into the curves. Complete the base course before proceeding to the second course.



3. Install Additional Courses

Starting with straight areas first, begin placing the second course. Center each unit on the seams of the course below in a running bond pattern as shown. Now proceed to the next layer, backfilling as you go. For drainage behind the wall, clean gravel or crushed stone is recommended.



Remove Edges

To remove outside lugs or edges of retaining lip, hold unit securely or place at angle on ground. Strike the lug firmly with a hammer. Always wear safety glasses to protect eyes from chips.



Building Curves

Curves as small as 2'-2" (660mm) in radius can be built with 4-in x 11.5-in Wall Block. Convex & concave course bonding will adjust sideways. If stack bond occurs, remove rear interlock lip as shown or cut units accordingly to get back to running bond.



Typical Wall Section

Use clean granular backfill such as gravel or crushed stone for drainage and to prevent soil from leaching through the wall. A commercial filter fabric (stocked by most garden supply stores) may be used when existing site soils are used for backfill.



Keystone Retaining Wall Systems LLC • A Contech Company
 4444 West 78th Street • Minneapolis, MN 55435
 (952) 897-1040 • www.keystonewalls.com

©2017 Keystone Retaining Wall Systems LLC

